

Bäumr-AG



58V Battery Powered Blower

User Manual

[Revision 1.0 April 2018]

READ THIS MANUAL CAREFULLY BEFORE USE – FAILURE TO DO SO MAY RESULT IN INJURY, PROPERTY DAMAGE AND MAY VOID WARRANTY. • KEEP THIS MANUAL FOR FUTURE REFERENCE. • Products covered by this manual may vary in appearance, assembly, inclusions, specifications, description and packaging.

Safety

Safety messages are designed to alert you to possible dangers or hazards that could cause death, injury or equipment or property damage if not understood or followed. Safety messages have the following symbols:

 You WILL be KILLED or SERIOUSLY INJURED if you do not follow instructions.	 You CAN be KILLED or SERIOUSLY INJURED if you do not follow instructions.	 You CAN be INJURED if you do not follow instructions or equipment damage may occur.
<p>It is vital that you read and understand this user manual before using the product, including safety warnings, and any assembly and operating instructions. Keep the manual for future reference.</p> <p>Safety precautions and recommendations detailed here must be fully understood and followed to reduce the risk of injury, fire, explosion, electrical hazard, and/or property damage.</p> <p>Safety information presented here is generic in nature – some advice may not be applicable to every product. The term "equipment" refers to the product, be it electrical mains powered, battery powered or combustion engine powered.</p> <ul style="list-style-type: none"> Before Use - If you are not familiar with the safe operation/handling of the equipment, or are in any way unsure of any aspect of suitability or correct use for your application, you should complete training conducted by a person or organization qualified in safe use and operation of this equipment, including fuel/electrical handling/safety. Do NOT operate the equipment in flammable or explosive environments, such as in the presence of flammable liquids, gases or dust. The equipment may create sparks or heat that may ignite flammable substances. Keep clear of moving parts. Equipment may be a potential source of electric shock or injury if misused. Do NOT operate the equipment if it is damaged, malfunctioning or is in an excessively worn state. Do NOT allow others to use the equipment unless they have read this manual and are adequately trained. Keep packaging away from children – risk of suffocation! Operators must use the equipment correctly, consider conditions and pay due care to persons and property. Ensure that any property that may be damaged by equipment failure is not within the work area / operating range. 	<p>General Personal Safety</p> <ul style="list-style-type: none"> Wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect from eye and ear injury, poisoning, burns, cutting and crush injuries. Protective equipment such as safety goggles, respirators, non-slip safety footwear, hard hat, hearing protection etc should be used for appropriate equipment / conditions. Other people nearby should also wear appropriate personal protective equipment. Do not wear loose clothing or jewellery, which can be caught in moving parts. Keep hair and clothing away from the equipment. Stay alert and use common sense when operating the equipment. Do not over-reach. Always maintain secure footing and balance. Do not use the equipment if tired or under the influence of drugs, alcohol or medication. This equipment is not intended for use by persons with reduced physical, sensory or mental capabilities. <p>General Fuel Safety</p> <ul style="list-style-type: none"> Petrol/fuel/gasoline is extremely flammable – keep clear of naked flames or other ignition sources. Do not spill fuel. If you spill fuel, wipe it off the equipment immediately – if fuel gets on your clothing, change clothing. Do NOT smoke near fuel or when refuelling. Always shut off the engine before refuelling. Do NOT refuel a hot engine. Open the fuel cap carefully to allow any pressure build-up in the tank to release slowly. Always refuel in well ventilated areas. Always check for fuel leakage. If fuel leakage is found, do not start or run the engine until all leaks are fixed. <p>General Work Area Safety</p> <ul style="list-style-type: none"> Work areas should be clean and well lit. Do not operate the equipment if bystanders, animals etc are within operating range of the equipment or the general work area. If devices are provided for connecting dust extraction / collection facilities, ensure these are connected and used properly. Dust collection can reduce dust-related hazards. 	<p>General Equipment Use and Care</p> <ul style="list-style-type: none"> The equipment is designed for domestic use only. Handle the equipment safely and carefully. Before use, inspect the equipment for misalignment or binding of moving parts, loose components, damage or any other condition that may affect its operation. If damaged, have the equipment repaired by an authorised service centre or technician before use. Prevent unintentional starting of the equipment - ensure equipment and power switches are in the OFF position before connecting or moving equipment. Do not carry equipment with hands or fingers touching any controls. Remove any tools or other items that are not a part of the equipment from it before starting or switching on. Do not force the equipment. Use the correct equipment for your application. Equipment will perform better and be safer when used within its design and usage parameters. Use the equipment and accessories etc. in accordance with these instructions, considering working conditions and the work to be performed. Using the equipment for operations different from those intended could result in hazardous situations. Always keep equipment components (engines, hoses, handles, controls, frames, housings, guards etc) and accessories (cutting tools, nozzles, bits etc) properly maintained. Keep the equipment clean and, where applicable, properly lubricated. Store the equipment out of reach of children or untrained persons. To avoid burns or fire hazards, let the equipment cool completely before transporting or storing. Never place or store the equipment near flammable materials, combustible gases or liquids etc. The equipment is not weather-proof, and should not be stored in direct sunlight, at high ambient temperatures or locations that are damp or humid. Do not clean equipment with solvents, flammable liquids or harsh abrasives. For specific equipment safety use and care, see Equipment Safety.

General Battery and Charging Safety	General Electrical Safety	General Service Information
<ul style="list-style-type: none"> Use only with the batteries and battery charger specified by the manufacturer. When battery is charged, disconnect the charger from the power supply and remove the battery from the charger. Batteries can explode in the presence of an ignition source, such as a pilot light. To reduce the risk of serious personal injury, never use any cordless product in the presence of open flame. Exploding batteries can propel debris and chemicals. Do not use the charger in wet areas or expose it to rain or water. Do not open the battery – danger of short-circuiting and/or explosion. Do not attempt to destroy or disassemble the battery pack or remove any of its components. Do not touch the battery terminals with metal objects and/or body parts as short-circuit and/or personal injury may result. Explosion hazard – protect the battery against heat; for example, direct sunlight and fire. Do not store batteries in vehicles or locations subject to heat. Explosion hazard – do not open and/or short-circuit the battery. Poison hazard – battery leakage (liquid ejection). Under extreme conditions, liquid may be ejected from the battery – avoid contact. If contact accidentally occurs, immediately seek medical attention, and flush with water. If liquid contacts eyes, immediately seek medical attention, flush with clean water for at least 10 minutes. Liquid ejected from the battery may cause irritation or burns. Ensure that the battery charger electrical cord is not subjected to damage or stress. Do not operate the battery charger if it has a damaged electrical cord or plug. For best results, charge batteries in temperatures between 7°C (45°F) and 40°C (104°F). Dispose of non-serviceable batteries in an environmentally responsible manner and according to local regulations. 	<ul style="list-style-type: none"> Inspect electrical equipment, extension cords, power bars, and electrical fittings for damage or wear before each use. Repair or replace damaged equipment immediately. Ensure all power sources conform to equipment voltage requirements and are disconnected before connecting or disconnecting equipment. When wiring electrically powered equipment, follow all electrical and safety codes. Wherever possible, use a residual current device (RCD). High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal. Electrically grounded equipment must have an approved cord and plug and be connected to a grounded electrical outlet. Do NOT bypass the ON/OFF switch and operate equipment by connecting and disconnecting the electrical cord. Do NOT use equipment that has exposed wiring, damaged switches, covers or guards. Do NOT use electrical equipment in wet conditions or in damp locations. Do NOT use electrical cords to lift, move or carry equipment. Do NOT coil or knot electrical cords, and ensure electrical cords are not trip hazards. 	<ul style="list-style-type: none"> The equipment must be serviced or repaired at authorised service centres by qualified personnel only. Replacement parts must be original equipment manufacturer (OEM) to ensure equipment safety is maintained. Do NOT attempt any maintenance or repair work not described in this manual. After use, the equipment and components may still be hot – allow the equipment to cool and disconnect spark plugs and/or electrical power sources and/or batteries from it before making adjustments, changing accessories or performing repair or maintenance. Do NOT make adjustments while the equipment is running. Perform service related activities in suitable conditions, such as a workshop. Replace worn, damaged or missing warning/safety labels immediately.

Safety Symbols

The product may have safety warning labels attached to it, explained below. Understand the symbols on your product and their meanings. If any stickers become unreadable, unattached etc, replace them.

 <p>Flammable Material Hazard Flammable liquids, gases or substances etc may present. Avoid ignition sources and open flames. Danger of fire.</p>	 <p>Read User Manual Read and fully understand product safety warnings, operation, procedures etc before using the product.</p>	 <p>Use Hand Protection Wear appropriate hand protection and take due care as the product or use of the product may present hand hazards.</p>	 <p>Carbon-Monoxide Hazard Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.</p>
 <p>Electrocution / Electrical Shock Hazard High voltage or high current electricity may be present or required by the product. Take due care when handling electrical products, cables, plugs and leads. Electrical shock can be fatal.</p>	 <p>Toxic Fumes hazard Using the product or by-products from use may produce fumes, smoke or particles that could be harmful if inhaled. Wear appropriate breathing protection and have adequate ventilation.</p>	 <p>Explosive Material Hazard Combustible liquids, gases or substances etc may be present. Avoid ignition sources and open flames. Danger of explosion.</p>	 <p>Cutting / Amputation Hazard The product may have blades, edges or mechanical devices that can cause severe cut injury to fingers, limbs etc. Take due care when handling and using the product.</p>
 <p>Crush Hazard The product may have blades, edges or mechanical devices that can cause severe crush injury to fingers, limbs etc. Take due care when handling and using the product.</p>	 <p>Single Operator Only The product must be operated by a single person only. More than one person operating the product may introduce additional hazards.</p>	 <p>Use Face Protection Wear appropriate full-face protection and take due care as the product or use of the product may present face and eye hazards.</p>	 <p>Use Foot Protection Wear appropriate foot protection and take due care as the product or use of the product may present foot hazards.</p>
 <p>Use Eye / Ear / Head Protection Wear appropriate eye and / or ear and / or head protection and take due care as the product or use of the product may present eye, hearing and head hazards.</p>	 <p>Running Hazard Do not run on or near the product as doing so may present a fall hazard.</p>	 <p>Diving Hazard Do not dive into the product as doing so may present a neck / head injury hazard.</p>	 <p>Adult Supervision Required Always supervise children and other users of a product to prevent drowning or injury.</p>
 <p>Skin Penetration / Puncture Hazard The product may produce pressure, emit liquids or objects that can cause severe injury to fingers, limbs, blood etc. Take due care when handling and using the product.</p>	 <p>Hot Surface Hazard Be aware that the product may produce high temperatures and hot surfaces that can cause burn injuries.</p>	 <p>Flying Debris Hazard Be aware that the product or use of the product may present hazards produced by flying debris. Wear appropriate clothing and protective devices.</p>	 <p>Moving Parts Hazard Be aware that the product contains or uses mechanical devices that move or rotate. Always wait for moving parts to stop fully before handling the product, adjusting, maintenance etc.</p>

 <p>Carbon-Monoxide Hazard Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.</p>	 <p>Pull Hazard Be aware that the product contains or uses mechanical devices that can pull in objects and can cause severe injury to fingers, limbs etc. Take due care when handling and using the product.</p>	 <p>Slope / Fall Injury Hazard Be aware that using the product on sloping surfaces or in slippery conditions may present additional dangers from falls and contact with blades, moving parts, hot surfaces etc.</p>	 <p>"Slam Dunk" Warning Do NOT attempt "slam dunk" manoeuvres as this may result in severe injury due to falling, product breakage or collapse etc.</p>
 <p>Electrocution / Electrical Shock Hazard - Outdoor High voltage or high current electricity may be present or required by the product. Do NOT use in rain, damp or wet conditions. Electrical shock can be fatal.</p>	 <p>Electrocution / Electrical Shock Hazard - Disconnect High voltage or high current electricity may be present or required by the product. Always disconnect the product from the electrical supply before handling the product, adjusting, maintenance etc.</p>	 <p>Power Line Electrocution Hazard High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal.</p>	 <p>"Kick-Back" Hazard High level of "kick-back" hazard that can cause the machine to suddenly rotate towards operator. Kick-back injury can be fatal.</p>
 <p>Winch Operator Position Hazard Do NOT stand between winch and load. Do NOT use winch to move people.</p>	 <p>Winch Lift Hazard Do NOT LIFT load vertically. Use machine to PULL only.</p>	 <p>Cable Hazard Ensure that load bearing cable is not kinked or knotted.</p>	 <p>Winch Cable Hazard Ensure that there is a minimum number of cable coils on winching mechanism.</p>
 <p>Winch Hook Hazard Carry hook to load – do NOT throw or run.</p>			

Equipment Safety



Powered garden blowers can cause serious injury if not used correctly or without taking proper safety precautions. **It is extremely important that you read and fully understand the information in this section and all other safety warnings / recommendations and usage instructions before using the equipment.**

Operator

- If you are untrained in the use of a tool or particular accessory, it is highly recommended that you be trained/instructed by a suitably qualified or experienced user before using the tool.
- NEVER operate the tool when tired, or under the influence of any substance (medication, alcohol, drugs etc) that may impair your judgement, alertness, physical strength, vision or dexterity.
- Maintain sure-footing and balance always when using or handling the tool and have full awareness of your surroundings and any possible hazards.
- Prolonged use may lead to health complications, such as carpal tunnel syndrome, due to vibration. To help reduce the possibility of such conditions, wear gloves, take breaks frequently, keep fingers and hands warm, and maintain the equipment for optimal operation and minimal vibration. It is recommended to seek medical advice if you feel numbness or burning sensations in fingers/hands.

Clothing and Protective Equipment – All Operators and Assistants

- Wear approved safety goggles, or safety glasses with adequate top and side protection. In addition to eye protection, wearing a full-face shield is highly recommended.
- Wear suitable hearing protection.
- Wear heavy-duty, non-slip leather or protective gloves.
- Wear approved heavy-duty safety boots, with steel toe-caps and non-slip soles.
- Wear suitable overalls or work clothing that fits snugly, but does not restrict movement.

Work Area Safety

- Ensure that any person, animal etc other than the operator is kept a minimum 25m (75') away from where the tool is being used or where there is any possibility of being struck by blown material etc. Be aware of any property that may be affected by blown material etc.

Operational Safety

- Do NOT use the tool if the trigger or any safety guard or mechanism is not installed or is not operating correctly – have the tool inspected and repaired at an authorised service centre before using it again.
- Fully understand how to safely operate the tool. See Operation.
- Always hold the tool firmly during operation. Always use the tool handles, straps etc.
- Do NOT use the tool for purposes it is not designed for.

Transportation Safety

- Always STOP the tool and remove the battery before transporting or working on it (adjusting etc).
- When transporting the tool in a vehicle, ensure the battery is removed. Secure the tool in an upright position to prevent tip-over or damage.
- Do NOT store batteries in direct sunlight or hot environments, such as vehicle interiors, for any period.

Table of Contents

Safety	2
Safety Symbols	4
Equipment Safety	6
Parts Identification	8
Batteries and Battery Charging	9
Charging	9
Assembly	10
Operation	10
Using the Controls.....	10
Cleaning, Transportation and Storage	11
Cleaning Guidelines.....	11
Preparing for Transport and Storage.....	11
Troubleshooting	12
Specifications	12

Parts Identification

The tool comes with all parts required for normal domestic use, with various attachments supplied depending on model, or may be purchased separately. A basic toolkit may also be included. It is strongly recommended that you familiarise yourself with all major components of the tool before using it or performing any maintenance tasks. Some parts may come pre-assembled.



Products detailed in this manual may vary in appearance, inclusions, description and packaging from those shown or described.



No.	Name	No.	Name
1	Tool (includes motor and main tube)	3	Battery (may be included)
2	Secondary Tube	4	Battery Charger (includes cables) (may be included)

Batteries and Battery Charging



Batteries may come supplied in a low-charge condition for shipping reasons – charge before use. • A battery that is new or has not been used for a long period does not charge to full capacity until after approximately 5 charge/discharge cycles. • Do not recharge batteries after using them if they are not to be used for an extended period. • Recharge batteries only as and when required. • If the battery is warm after use, allow it to cool before charging, otherwise it may not fully charge. • Use only with the batteries and battery charger specified by the manufacturer. • Batteries can explode in the presence of an ignition source, such as a pilot light. Never use any cordless product in the presence of open flame. Exploding batteries can propel debris and chemicals. • Do not use the charger in wet areas or expose it to rain or water. • Ensure that the battery charger electrical cord is not subjected to damage or stress. Do not operate the battery charger if it has a damaged electrical cord or plug. • Do not open the battery – danger of short-circuiting and/or explosion. • Do not touch the battery terminals with metal objects and/or body parts as short-circuit and/or personal injury may result. • For best results, charge batteries in temperatures between 7°C (45°F) and 40°C (104°F). • Dispose of non-serviceable batteries in an environmentally responsible manner and according to local regulations. Charging time varies for different battery types depending on battery capacity and charger output etc. • To prolong battery life, avoid leaving the battery pack on charge for extended periods (over 30 days without use). • During charging, the battery may become warm and some noise may be emitted – this is normal.

Charging

Generally, if the tool stops during use, or the motor slows considerably, it indicates that the battery needs charging. To remove the battery (A), push the battery release (B) toward the battery and hold, then pull the battery from the tool.




Batteries have a display built-in that shows current charge percentage and battery temperature. To use the functions, press button (C) on the battery – charge percentage shows for a brief period. Press the button again whilst the display is active to show battery temperature.



The battery charger has charge status LED indicators that illuminate and flash in various combinations:

- **Red** - No battery detected.
- **Red Flash** - Battery fault detected.
- **Red ON / Green Flash** – Charging.
- **Red ON / Green ON** – Charging near complete.
- **Red Flash / Green Flash** - Battery charged.

1. Plug the battery charger (D) into an electrical outlet and switch on.
2. Slide the battery fully into the battery charger. The battery charger indicator LEDs will indicate battery charge status. Charging time varies depending on the battery capacity and charger output.
3. When the battery is fully charged, unplug the charger from power supply and remove the battery pack.



Assembly

- With the foot (X) of the secondary tube (B) facing down, push the tube onto the tool main tube (A) until the tabs (Y) "clip" into the secondary tube.



To disconnect the tubes, press and hold the locating tabs in, then pull the secondary tube from the main tube.

Operation



Powered garden blowers can cause serious injury if not used correctly or without taking proper safety precautions. **It is extremely important that you read and fully understand the information in this section and all other safety warnings / recommendations and usage instructions before using the equipment.**

Using the Controls

- To activate the motor, push the ON / OFF switch (A) forward to the "ON" ("I") position.
- To adjust blower air speed, rotate the speed control (B) as required – rotate right (clockwise) to increase speed, rotate left (anti-clockwise) to reduce speed.
- To engage maximum air speed, press and hold the maximum speed button (C).
- To switch the motor off, pull the ON / OFF switch backward to the "OFF" ("O") position.



Cleaning, Transportation and Storage



Always ensure that the tool is cool enough to touch before transporting or storing. • Always transport and store the tool with the battery removed. • Do NOT store the tool or battery in direct sunlight or

Cleaning Guidelines



Do NOT expose any part of the tool to water. Exposure to water may create an electrical shock hazard and / or may damage the electronics. **Exposing the tool to water or other liquids may void any product warranty.** • Remove the battery from the tool before cleaning. • Do not use solvents, chemicals or abrasives when cleaning the tool, as some surfaces may be damaged. • Clean the tool after every use to ensure best performance and longest service life. • Do NOT store batteries in direct sunlight or hot environments, such as vehicle interiors, for any period.

- Use a slightly damp cloth and mild detergent for cleaning.
- Use a brush for parts that are difficult to reach.
- Ensure air vents and surfaces designed for heat dissipation are clean and free of obstructions or debris.
- Ensure that all control cables, levers, switches etc are clean and operate normally and smoothly.

Preparing for Transport and Storage

- Clean the tool before transport or storage.
- Ensure the battery is removed.
- When transporting the tool in a vehicle, secure the tool in an upright position to prevent tip-over or damage.
- Store the tool in a dry, well-ventilated area that is not exposed to direct sunlight or excessive heat, and out of the reach of children.
- Cover the tool to protect it.

Troubleshooting



Do NOT perform and maintenance or troubleshooting procedures with the battery installed in the tool. • The tool should be cool enough to touch before performing maintenance activities. • Some maintenance activities described may be beyond the scope of some users. For procedures that you are not comfortable with or have the tools, knowledge or experience for, have the unit serviced by a service centre or qualified technician.

The following information may assist in identifying a problem and rectifying it.

Difficulty starting the tool.

Possible Fault	Action
Incorrect procedure	Press the trigger safety button in and hold, then squeeze the trigger.
	
No voltage	Ensure the battery is charged and is correctly inserted.
	
Battery or control switch faulty	Have battery and / or tool tested and repaired at an authorised service centre.

Tool slows or stops suddenly during use.

Possible Fault	Action
No voltage	Ensure the battery is charged and is correctly inserted.

Specifications

Battery Charger Electrical Requirements	240VAC / 50Hz
Battery Type	58V Lithium-Ion



Some experts believe the incorrect or prolonged use of almost any product could cause serious injury or death. For information that may reduce your risk of serious injury or death, consult the points below and additionally, the information available at www.datastreamserver.com/safety

- Consult all documentation, packaging and product labelling before use. Note that some products feature online documentation which should be printed and kept with the product.
- Check product for loose / broken / damaged / missing parts, wear or leaks (if applicable) before each use. Never use a product with loose / broken / damaged / missing parts, wear or leaks (if applicable).
- Products must be inspected and serviced (if applicable) by a qualified specialist every 6 months assuming average residential use by a person of average weight and strength, above average technical aptitude, on a property matching average metropolitan specification. Intended use outside these guidelines could indicate the product is not suitable for intended use or may require more regular inspection or servicing.
- Ensure all possible users of the product have completed an industry recognized training course before being given access to the product.
- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or your description of the application. Be sure to attain third-party approval for your application from a qualified specialist before use regardless of prior assurances by the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (take an automobile, aircraft, computer or ball point pen for example), there is always a small chance of technical issues that needs to be repaired or may require replacement of the product or a part. If the possibility of such failure and the associated time it takes to rectify could in any situation inconvenience the user, business or employee then the product is not suitable for your requirements. This product is not for use where incorrect operation or a failure of any kind, including but not limited to a condition requiring product return, replacement, service by a technician or replacement of parts could cause a financial loss, loss of employee time or an inconvenience requiring compensation.
- If this item has been purchased in error after considering the points above, simply contact the retailer directly for details of their returns policy, if required.

Bäumr-AG®
com.au

©2018 Bäumr-AG. All rights reserved. No part of this document, including descriptive content, concepts, ideas, diagrams or images may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, scanning or recording, or any information storage and retrieval system, without express permission or consent from the publisher.