


Wooden Toy Kitchen

Assembly instructions

Please retain this information
for future reference



WARNING:
ADULT ASSEMBLY REQUIRED.
Product includes small parts with potentially hazardous sharp
points and sharp edges in the unassembled state.
Keep unassembled parts away from children.



