


Wooden Pirate Play Set

Assembly instructions

Please retain this information for future reference



WARNING:

ADULT ASSEMBLY REQUIRED.


Product includes small parts with potentially hazardous sharp points and sharp edges in the unassembled state.

Keep unassembled parts away from children.


CHOKING HAZARD. Small parts and sharp points, not suitable for children under 3 years.




1




2














3



4



5**6****7****8****9****10**

11**12****13****14****15****16**