

Bäumr-AG



20V LED Torch TR2

User Manual

[Revision 1.0 August 2017]

READ THIS MANUAL CAREFULLY BEFORE USE – FAILURE TO DO SO MAY RESULT IN INJURY, PROPERTY DAMAGE AND MAY VOID WARRANTY. • KEEP THIS MANUAL FOR FUTURE REFERENCE. • Products covered by this manual may vary in appearance, assembly, inclusions, specifications, description and packaging.

Safety

Read and understand all safety warnings before using the tool.

- Do not use this product if it is not completely assembled or if any parts appear to be missing or damaged. Use of a product that is not properly and completely assembled could result in serious personal injury.
- Inspect the tool carefully to make sure no breakage or damage occurred during shipping.
- If any parts are damaged or missing do not operate this tool until the missing parts are replaced. Use of this product with damaged or missing parts could result in serious personal injury.
- Do not attempt to modify this tool or create accessories not recommended for use with this tool. Any alteration or modification is misuse that will void product warranty and could result in a hazardous condition leading to possible serious personal injury.
- Keep the tool and all components away from children.
- Do not allow persons unfamiliar with the tool or its operation to use the tool.
- Only use parts and accessories recommended by manufacturer.
- Do not modify any part of the tool or its safety mechanisms.
- Do not use in ambient temperatures above 40°C (104°F).
- Do not shine the torch directly into eyes.

Battery and Charging Safety

- Use only with the batteries and battery charger specified by the manufacturer.
- Do not open the battery – danger of short-circuiting.
- Do not attempt to destroy or disassemble battery pack or remove any of its components.
- Do not touch the battery terminals with metal objects and/or body parts as short-circuit and/or personal injury may result.
- Explosion hazard – protect the battery against heat; for example, direct sunlight and fire.
- Explosion hazard – do not short-circuit the battery.
- Poison hazard – battery leakage (liquid ejection) may cause irritation or burns. Under extreme conditions, liquid may be ejected from the battery – avoid contact. If contact occurs, flush with water. If eye contact occurs, flush with clean water for at least 10 minutes and seek medical attention.
- Care when charging. Make sure cord for the battery charger is located so that it will not be stepped on, tripped over, or otherwise subjected to damage or stress. Do not operate the battery charger if it has a damaged cord or plug.
- Dispose of non-serviceable batteries in an environmentally responsible manner.

Servicing

- Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that safety of the tool is maintained.

Intended Use

- Illumination.

Table of Contents

Safety	2
Parts Identification.....	4
Batteries and Battery Charging	5
Charging.....	5
Inserting and Removing the Battery Pack.....	5
Operation	6
Maintenance and Troubleshooting	7
Specifications.....	7

Parts Identification



No.	Name	No.	Name
1	Tool Body	4	Battery
2	Torch Head	5	Strap
3	ON / OFF Switch	6	Battery Charger

Batteries and Battery Charging



Batteries for this tool are supplied in a low-charge condition for shipping reasons. • A battery that is new or has not been used for a long period does not charge to full capacity until after approximately 5 charge/discharge cycles. • Do not recharge batteries after using them if they are not to be used for an extended period of time. • Recharge batteries only as and when required. • If the battery is warm after use, allow it to cool before charging, otherwise it may not fully charge.

The battery packs can be recharged again and again. However, rechargeable batteries eventually need to be replaced. A significantly reduced working period after charging indicates that the battery is no longer serviceable and should be replaced. Discard old batteries in an environmentally responsible manner.

Charging

The battery charger has charge status LED indicators:

- **Red** - Battery charging.
- **Green** - Battery fully charged.

1. Plug the battery charger power supply into a 240VAC mains electrical outlet and switch the supply ON.
2. Slide the battery fully into the battery charger. The indicator LED on the battery charger will be red to show the battery is charging. The indicator will become green when the battery is fully charged (approximately 1 to 1.5 hours).
3. When the battery is fully charged, unplug the charger from power supply, then press and hold the battery release button and simultaneously slide the battery pack from the charger.



Inserting and Removing the Battery Pack

Insert the battery pack into the tool handle until it "clicks" into place.

To remove the battery pack, press and hold the battery release button (A) and simultaneously pull the battery from the tool.



Operation



Fully understand all operational [safety warnings](#) before using the tool. • The light output is high intensity - do not shine the torch directly in eyes.

1. To switch the torch on, press the ON / OFF switch (A).
2. To switch the torch off, press the ON / OFF switch (A).
3. Rotate the torch head (B) as needed by holding the tool body, then rotating the torch head up or down.



Maintenance and Troubleshooting



Remove the battery from the tool before performing any maintenance. • Some maintenance activities described may be beyond the scope of some users. For procedures that you are not comfortable with or have the tools or experience for, have the unit serviced by a service centre or qualified technician.

- Clean the tool regularly with a soft cloth – do NOT use water, solvents, abrasives etc.

The following information may assist in identifying a problem and rectifying it.

Torch will not operate.

Possible Fault	Action
No voltage	Ensure the battery is charged and is correctly inserted.
ON / OFF switch not set	Press ON / OFF switch.
Lamps no longer functional	Replace tool.

Specifications

Battery Charger Electrical Requirements	240VAC / 50Hz
Battery Type	20V Lithium-Ion
Torch	9 x LED



Some experts believe the incorrect or prolonged use of almost any product could cause serious injury or death. For information that may reduce your risk of serious injury or death, consult the points below and additionally, the information available at www.datastreamserver.com/safety

- Consult all documentation, packaging and product labelling before use. Note that some products feature online documentation which should be printed and kept with the product.
- Check product for loose / broken / damaged / missing parts, wear or leaks (if applicable) before each use. Never use a product with loose / broken / damaged / missing parts, wear or leaks (if applicable).
- Products must be inspected and serviced (if applicable) by a qualified specialist every 6 months assuming average residential use by a person of average weight and strength, above average technical aptitude, on a property matching average metropolitan specification. Intended use outside these guidelines could indicate the product is not suitable for intended use or may require more regular inspection or servicing.
- Ensure all possible users of the product have completed an industry recognized training course before being given access to the product.
- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or your description of the application. Be sure to attain third-party approval for your application from a qualified specialist before use regardless of prior assurances by the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (take an automobile, aircraft, computer or ball point pen for example), there is always a small chance of technical issues that needs to be repaired or may require replacement of the product or a part. If the possibility of such failure and the associated time it takes to rectify could in any situation inconvenience the user, business or employee then the product is not suitable for your requirements. This product is not for use where incorrect operation or a failure of any kind, including but not limited to a condition requiring product return, replacement, service by a technician or replacement of parts could cause a financial loss, loss of employee time or an inconvenience requiring compensation.
- If this item has been purchased in error after considering the points above, simply contact the retailer directly for details of their returns policy, if required.

Bäumr-AG[®]
.com.au

©2017 Bäumr-AG. All rights reserved. No part of this document, including descriptive content, concepts, ideas, diagrams or images may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, scanning or recording, or any information storage and retrieval system, without express permission or consent from the publisher.