



1000LB MOTORCYCLE LIFT

User Manual



RETAIN THIS MANUAL FOR FUTURE REFERENCE

PLEASE READ THIS MANUAL CAREFULLY BEFORE USE


Table of Contents

WARNING	1
ASSEMBLY DIAGRAM	2
IMPORTANT	3
Parameter	3
Features.....	3
Operation	3
Maintenance	3
PARTS LIST	4

WARNING

1. Always check the lift before use.
2. Do not operate under the table, keeping hands and body away from the table when it's operating. The air hose should be pulled from the bottom, not on the table.
3. When lowering the table, take care to control the speed of descent.
4. When the table is at its highest elevated position, do not attempt to pump the table higher, as this can damage the mechanism.

ASSEMBLY DIAGRAM



IMPORTANT

Please read this instruction manual carefully. Note the safety instructions & warnings. Use this product correctly and with care. Use it only for the purpose for which it is intended.

Parameter

Capacity: 1000 LBS

Min. Height: 210 MM

Max Height: 780 MM

Features

1. Air or Hydraulic Powered Mechanism
2. Removable plate for increased access, such as rear wheel removal
3. Adjustable foot for increased safety and stability
4. Safety set increases safety against accidental descent of table

Operation

1. Ensure that the table is at the minimum height, and that the ramp is in place.
2. Lock off the release valve, pump the foot pedal steadily until the table reaches a required height, or use the air pump to lift the motorcycle lift. Connect the hose to the air feeder directly before operating the air pump, then press the valve to elevate the table. Loosen the valve to stop.
3. Lock the safety set at the required height. Then repair the motorcycle.
4. After repairing, remove the safety set.
5. Pump the foot pedal steadily to decrease the table's elevation.
6. Remove the motorcycle from its stand and wheel it off the back of the table via the ramp.

Maintenance

1. The mechanical parts of the lift, such as the foot pedal and release shafts should be occasionally lubricated with heavy oil or grease.
2. Protect the lift cylinder from dirt or dust. If it becomes dirty, wipe it off with a clean cloth.
3. Maintain and store the lift in a reasonably protected environment. Do not expose to rain or excess moisture. Protect it from salt water or other corrosive materials.

PARTS LIST

Part No.	Description	Qty.	Part No.	Description	Qty.
1	Hydraulic Motorcycle Lift	1	9	Plane Spare $\Phi 10$	2
2	Leading Plate	1	10	Spring Washer $\Phi 10$	2
3	Clamp(A)	1	11	Nut M10	2
4	Bolt M8x30	2	12	Plane Spacer $\Phi 8$	4
5	Bolt M8x20	2	13	Spring Washer $\Phi 8$	4
6	Clamp(B)	1	14	Nut M8	4
7	Bolt M10x25	2	15	Pin $\Phi 10 \times 80$	2
8	Back Plate	1	16	Pin $\Phi 12 \times 90$	1



Some experts believe the incorrect or prolonged use of almost any product could cause serious injury or death. For information that may reduce your risk of serious injury or death consult the points below and additionally, the information available at www.datastreamserver.com/safety

- Consult all documentation, packaging and product labelling before use. Note that some products feature online documentation which should be printed and kept with the product.
- Check product for loose / broken / damaged / missing parts, wear or leaks (if applicable) before each use. Never use a product with loose / broken / damaged / missing parts, wear or leaks (if applicable).
- Products must be inspected and serviced (if applicable) by a qualified specialist every 6 months assuming average residential use by a person of average weight and strength, above average technical aptitude, on a property matching average metropolitan specification. Intended use outside these guidelines could indicate the product is not suitable for intended use or may require more regular inspection or servicing.
- Ensure all possible users of the product have completed an industry recognised training course before being given access to the product.

- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or your description of the application. Be sure to attain third party approval for your application from a qualified specialist before use regardless of prior assurances by the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (take an automobile, aircraft, computer or ball point pen for example) there is always a small chance of a technical issue that needs to be repaired or may require replacement of the product or a part. If the possibility of such failure and the associated time it takes to rectify could in any situation inconvenience the user, business or employee or could financially affect the user, business or employee then the product is not suitable for your requirements. This product is not for use where incorrect operation or a failure of any kind, including but not limited to a condition requiring product return, replacement, service by a technician or replacement of parts could cause a financial loss, loss of employee time or an inconvenience requiring compensation.
- If this item has been purchased in error considering the points above simply contact the retailer directly for details of their returns policies if required.