



Hi there, thanks for purchasing our Graig gazebo/tent!


Please see next page for full setup and assembly instructions.

All our poles are numbered below and also have numbered stickers on the pole for easy identification.

We hope that you enjoy your special occasion.

Please visit mytopia.com.au for other great outdoor products!

GAZEBO SETUP


1		Open gazebo frame so it is roughly 1m x 1m and place the roof over it (try to match the corners)
2		Gently lift the gazebo and straighten out the base diagonally
3		From the center of the gazebo, push up and expand until the roof can easily fit over corners. DO NOT FULLY EXPAND YET!
4		Ensuring that each corner of the roof nicely fits over the corner of the frame, gently slide the corner tube over pin until pin pops out of tube hole. This is to ensure there's no ripping of roof while frame is fully extended
5		Now that the frame is fully extended and roof is taut, extend each leg
6		Place the gazebo on a flat surface

Please Note

Please be cautious when using the gazebo on windy days

For occasions where heavy wind may occur, below are some options for stability


1. Tie down sand bags to each foot



2. Tie rope to each corner and peg into ground



3. If set up on concrete, bolt down feet/base into concrete using dynabolts



ALSO, A FRIENDLY REMINDER THAT THESE GAZEBO'S ARE NOT DESIGNED FOR PERMANENT SHELTERS



Some experts believe the incorrect or prolonged use of almost any product could cause serious injury or death. For information that may reduce your risk of serious injury or death consult the points below and additionally, the information available at www.datastreamserver.com/safety

- Consult all documentation, packaging and product labelling before use. Note that some products feature online documentation which should be printed and kept with the product.
- Check product for loose / broken / damaged / missing parts, wear or leaks (if applicable) before each use. Never use a product with loose / broken / damaged / missing parts, wear or leaks (if applicable).
- Products must be inspected and serviced (if applicable) by a qualified specialist every 6 months assuming average residential use by a person of average weight and strength, above average technical aptitude, on a property matching average metropolitan specification. Intended use outside these guidelines could indicate the product is not suitable for intended use or may require more regular inspection or servicing.
- Ensure all possible users of the product have completed an industry recognised training course before being given access to the product.

- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or your description of the application. Be sure to attain third party approval for your application from a qualified specialist before use regardless of prior assurances by the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (take an automobile, aircraft, computer or ball point pen for example) there is always a small chance of a technical issue that needs to be repaired or may require replacement of the product or a part. If the possibility of such failure and the associated time it takes to rectify could in any situation inconvenience the user, business or employee or could financially affect the user, business or employee then the product is not suitable for your requirements. This product is not for use where incorrect operation or a failure of any kind, including but not limited to a condition requiring product return, replacement, service by a technician or replacement of parts could cause a financial loss, loss of employee time or an inconvenience requiring compensation.
- If this item has been purchased in error considering the points above simply contact the retailer directly for details of their returns policies if required.

