

HOSE WITH REEL


USER MANUAL

RETAIN THIS MANUAL FOR FUTURE REFERENCE


PLEASE READ THIS MANUAL CAREFULLY BEFORE USE

SET-UP

1. Fasten metal mounting to the wall or ceiling with screws.
2. Drill 2 M8 holes to match the holes located in the Mounting Bracket.



It is recommended to install the mounting bracket at least 80cm from the floor.



1. Pull the hose; it has 2-3 lock positions every metre.
2. Don't pull the hose when it has finished unwinding.
3. Hold the nozzle when the hose is retraced until your task is finished.

TROUBLESHOOTING

The most common malfunction is that the hose cannot be retracted automatically after fully extending the hose.

The reason may be that the hose end is locked as the 'stop-anywhere' mechanism stays in the locking point, and there is no extra hose to be pulled out for release. There are two ways to solve this:

1. Hold the hose at the yellow warning mark and pull with a jerking motion until the hose retracts.
2. Place the reel down on its right side, then pull on the hose until it retracts.



Some experts believe the incorrect or prolonged use of almost any product could cause serious injury or death. For information that may reduce your risk of serious injury or death consult the points below and additionally, the information available at www.datastreamserver.com/safety

- Consult all documentation, packaging and product labelling before use. Note that some products feature online documentation which should be printed and kept with the product.
 - Check product for loose / broken / damaged / missing parts, wear or leaks (if applicable) before each use. Never use a product with loose / broken / damaged / missing parts, wear or leaks (if applicable).
 - Products must be inspected and serviced (if applicable) by a qualified specialist every 6 months assuming average residential use by a person of average weight and strength, above average technical aptitude, on a property matching average metropolitan specification. Intended use outside these guidelines could indicate the product is not suitable for intended use or may require more regular inspection or servicing.
 - Ensure all possible users of the product have completed an industry recognised training course before being given access to the product.

- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or your description of the application. Be sure to attain third party approval for your application from a qualified specialist before use regardless of prior assurances by the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (take an automobile, aircraft, computer or ball point pen for example) there is always a small chance of a technical issue that needs to be repaired or may require replacement of the product or a part. If the possibility of such failure and the associated time it takes to rectify could in any situation inconvenience the user, business or employee or could financially affect the user, business or employee then the product is not suitable for your requirements. This product is not for use where incorrect operation or a failure of any kind, including but not limited to a condition requiring product return, replacement, service by a technician or replacement of parts could cause a financial loss, loss of employee time or an inconvenience requiring compensation.
- If this item has been purchased in error considering the points above simply contact the retailer directly for details of their returns policies if required.