



## BMW i8 INSPIRED RIDE-ON ELECTRIC CAR



**The battery may have some charge on arrival, it is important  
however that the battery is charged prior to use.**

Use the product please first read instructions, it will tell you the correct methods of operation and installation instructions. To avoid not correct methods of operation of this product damage or injury and your baby.

Manual should be placed to take good care of.

It's STANDARD NO.:EN71 EN62115

**The product to get c is the main ingredients of the important parts.**

## **SPECIFICATION**

<b>Motor:</b>	<b>70W (2 x 35W)</b>
<b>Speed Range:</b>	<b>2-8KPH</b>
<b>Speeds:</b>	<b>Dual (High/low)</b>
<b>Gears:</b>	<b>Forward and Reverse</b>
<b>Keystart Engine Sound:</b>	<b>Yes</b>
<b>Seat belts:</b>	<b>Adjustable</b>
<b>Battery:</b>	<b>12V 7Ah</b>
<b>Battery Charger:</b>	<b>AC100-240V 50/60Hz</b>
<b>Output:</b>	<b>DC12V 1000mA</b>
<b>Charge Time:</b>	<b>6-8hrs (full charge)</b>
<b>Range:</b>	<b>1-2hrs (full charge)</b>
<b>Remote Operation:</b>	<b>Yes</b>
<b>Remote Battery:</b>	<b>3 x AA Battery (Batteries not included)</b>
<b>Remote Distance:</b>	<b>20m (+/- 5m)</b>

## **SAFE RULES**



**Non-transportation, must be care of adult!**  
**Before using the child for education, safety!**

1. Be charged by an adult, don't let the children touch.
2. Driving, we must by adults, and the tutelage use.
3. Clamp down on the streets, roads, slope, waiting for over a backward, to eliminate obstacles to ride.
4. It's suitable for children for about 37-96 months.
5. Cycle shall not leave the seat to prevent operation resulting in injury.
6. In the car was pulled, the device, such as a block, please immediately release switch to eliminate the obstacles and foot before you ride.

## **CHARGE METHOD**

1. First to use please open the cushion , and the battery connections with main distributing frame, with red in red and black in black, not a line ends meet, or cause a short-circuit.
2. Charging socket the cushion down side, and needs recharging. charger plug in the outlet, then insert the power outlet.
3. The train slowly, in charge, the time for 8-10 hours, and not more than ten hours.
4. In the first to use the deposit, we must ensure that the cell battery up to 10 hours. otherwise, permanent damage cells and beyond repair.
5. Charging devices or battery which has a fever (60 °C) are normal.
6. The electric baby must use this car is equipped with the charger and the battery, in the case of broken the cell phone chargers and the counter-voltage or an electric circuit.
7. Have to recharge the batteries to be recharged from the toy the use of battery.
8. Not mixed with the old and new or different types of batteries.
9. Can't insert the battery wire connector.
10. When the baby is not use for a long time, at least once every month to charge.
11. Toys can't connect to the surplus on the use of the recommended amount.
12. When the car is charging,can't use it.

## **PACKING LIST**


• Car Body	1PC	• Gear box	2PC	• Arear axle	1PC
• Steering wheel	1PC	• Shim	6PC	• Remote control	1PC
• Chair	1PC	• Charger	1PC	• Cotter pin	4PC
• Wheel	4PC	• Mp3 Connecting line	1PC	•	
• Wheel cover	4PC	•		•	

## Video Tutorial:

### Typical Ride-On Car Assembly




## UNIT MOUNT



### Install rear wheel


First the gasket line enters into the front axle, Then on the front wheel sets, and then set into the sleeve gasket and loosen the nut, Cover with a nut wrench should be fixed, blocked shots.

About the same installation  
(as shown in figure 1)



### Install front wheel

Will first car body over, will be through the rear axle, gear box positioning on the car, and then the connectors on the gear box connected to connectors on the auto body, and then insert the rear wheel axle after, set into the sleeve gasket and the locknut, then its fixed with a nut wrench, finally cover the cap. About installation  
(same as shown in figure 2)




### Install shield

Will first windshield card slot Angle on the body card card, forcibly installed hear clicks.  
(as shown in figure 3)


**NOTE:** Please remove the terminal cover first when assembling the battery.

## UNIT MOUNT




### Install steering wheel

The steering wheel and the steering rodline connector line connectors connected together(note the positive and negative plug),and the steering wheel is sheathed in the direction of the rod,using M5 screw orderly passes through the steering wheel and the steering rod.



### The mounting seat




Before installing the seat will be the first power supply is connected with the positive pole,then the seat at the specified location,the hook body slots aligned,then the seat in front of the two-side fixing holes with ST4.0\*12 screws tighten clockwise.



### Install the rearview mirror.

Firstly, the rearview mirror or distinction, then the corresponding insert body.

## **UNIT MOUNT**



### **Installing remote control battery**

Please buy two AA1.5V batteries, then the controller below the battery cover is pushed in the direction of the arrow, open the cover of battery, the battery pack into a remote control, the battery lid.

### **Applique Schematic**

The brochure placed stickers removed, picture collage. The stickers on the dashboard and the wheel cap.

(as shown in figure 8)

### **Function description**

Start key switch, vehicle lights, move the steering wheel buttons to send out music, also on both sides of the body with the rhythm of music, flashing lights. In addition the sound device is controlled by the volume control (A total of 4-6 different music.)

The forward / backward switch is in the "on" position, step on the pedal switch, the car moving forward, will move back to the switch is in the "back" position, step on the pedal switch, the car backwards running. A remote forward rocker, the car automatically moving forward; the remote controller back rocker, the car automatically back exercise, a left rocker, the front wheel to rotate to the left, the right turn. Rocker, the front wheel to the right. (Note: the above function remote control is preferred)  
(As picture 9)

## TROUBLESHOOTING

PROBLEM	ANALYZE	SOLUTION
Car doesn't work	• Low power	Recharge the battery
	• Damage of thermic fuse	Change with new thermic fuse
	• Lose of wheel nut	Use new nut
	• Loose of battery connector	Put on the connector
	• Exhaust & bad battery	Change with new battery
	• Damage on electrical parts	Go to repair shop
	• Damage on motor	Go to repair shop
Battery can't be recharged	• Loose of the battery connector	Tighten the connector
	• Charger doesn't plug the power	Plug charger with power
	• Damage of charger	Change new charger
Short of run time	• Battery with lower power	Recharge the battery fully
	• Battery is old	Change new battery
Noise & Heat during recharge	• It's chemical process	It's normal & safety
Low Speed	• Old battery	Use new battery
	• Low power	Recharge the battery fully
	• Over burden	Reduce burden under 25KG
	• Run on not-flat ground	Run on flat ground
Noise of gear box	• Damage of gear box	Go to repair shop
	• Damage on motor	Go to repair shop
Car shake when running	• Bad connect of motor wire	Reconnect the wire
	• Motor doesn't work well	Go to repair shop
No sound & light when running	• Loose of sound & light wire	Connect the wire
	• Damage of sound & light board	Go to repair shop
Car can't stop in run	• Damage of electrical parts	Go to repair shop
	• Remote control battery exhaust	Change battery
Unusual working condition under Remote control	• Remote control out of distance	Keep near distance between car and remote control
	• Damage of remote control	Damage of remote control
	• Damage of receiver board	Change receiver board
	• Disturb of magnetic filed	Far away from magnetic filed

## **USE CAUTIONS**

- 1.In the first to use the deposit, we must ensure that the cell battery up to 10 hours. otherwise, permanent damage cells and beyond repair.
- 2.In the streets, roads, slope, ditch and the danger area.
- 3.Please don't on the polished surface, such as marble, tile on the surface.
- 4.This product by one, not limit, the greatest relief to over 30KG.
- 5.Don't run in an electric switch on deposit in the back of the light switch.
- 6.Shall not be altered the car circuit or device to additional charged
- 7.The remote control and not to let it get caught in the rain or otherwise made in water and keep away from sources of ignition to avoid causing the damage.
- 8.Met with obstruction, the baby stop, please leave the obstacles to ride.
- 9.Don't use in the water, water and other liquids in the car.
- 10.Not in use, to avoid hitting the child.
- 11.When the remote control battery power is low, the car on the remote control and turned back, a short distance, shake, please replace the battery!
- 12.Not in use, please turn off the switch. no, please unplug the battery, a connector.
13. The types of batteries that may be used.
14. How to remove and insert the batteries.
15. Non-rechargeable batteries are not to be recharged.
16. rechargeable batteries are only to be charged under adult supervision(for toys supplied with a battery charger for use by children, this instruction may be replaced by. " Batteries are only to be charged by adults or by children at least 8 years old")
17. Rechargeable batteries are to be removed from the toy before being charged.
18. Different types of batteries or new and used batteries are not to be mixed.
19. Batteries are to be inserted with the correct polarity.

20. Exhausted batteries are to be removed from the toy.
21. The supply terminals are not to be short-circuited.
22. Toys shall be provided with instructions for assembly if.
23. They are intended to be assembled by a child.
24. These instructions are necessary for safe operation of the toy.
25. Instructions shall be provided that give details concerning cleaning and maintenance when necessary for the safe operation of the toy.
26. They shall state that transformers or batterychargers used with the toy are to be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired.

## **DECLARATION:**

- 1) This product is only suitable for China's market for sale and use.
- 2) Manual used in illustrations to explain the product of the operations and products, with the installation of structure in the existence of a small difference in kind, please standard the object.
- 3) In order to improve product quality, not to notice, we may change the part of the structure, and appearance. please forgive.
- 4) This package contains important information that must be kept.
- 5) Cannot be used in rainy days.
- 6) Can not use water to clean.



**Some experts believe that the incorrect or prolonged use of almost any product may cause serious injury or death. To help reduce your risk of serious injury or death, refer to the information below. For more information, see [www.datastreamserver.com/safety](http://www.datastreamserver.com/safety)**

- Consult all documentation, packaging and product labelling before use. Note that some products feature documentation available online. It is recommended to print and retain the documentation.
- Before each use, check the product for loose/broken/damaged/missing parts, wear or leaks (if applicable). Never use a product with loose/broken/damaged/missing parts, wear or leaks.
- Products must be inspected and serviced (if applicable) by a qualified technician every 6 months. This is based on average residential use by persons of average size and strength, and on a property of average metropolitan size. Use beyond these recommendations may require more frequent inspections/servicing.
- Ensure that all users of the product have completed a suitable industry recognised training course before being allowed access to the product.
- If this product has been purchased in error when considering the information presented here, contact the retailer directly for details of their returns policy, if required.
- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or description of application. Be sure to attain third-party approval from a qualified specialist for your application before use, regardless of any assurances from the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (for example, automobile, computer, toaster), there is the possibility of technical issues that may require the repair or replacement of parts, or the product itself. If the possibility of such failure and the associated time it may take to rectify could in any way inconvenience the user, business or employee, or financially affect the user, business or employee, then the product is not suitable for your requirements. This product is not intended for use where incorrect operation or a failure of any kind, including but not limited to, a condition requiring product return, replacement, parts replacement or service by a technician may cause financial loss, loss of employee time or an inconvenience requiring compensation.



©2018 Rovo Kids. All rights reserved. No part of this document, including descriptive content, concepts, ideas, diagrams or images may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, scanning or recording, or any information storage and retrieval system, without express permission or consent from the publisher.