


# Craig Outdoor Umbrella - User Guide



## Safety

- The umbrella must be installed on a flat, level and hard surface. Do not use on grass or soft or uneven surfaces.
- When not in use, fully close the umbrella and secure it so that it does not get blown or knocked over.
- It is recommended to secure the base using weights, pavers etc.
- Do not use the umbrella in windy conditions.
- **Failure to assemble, use or care for the umbrella correctly may void any warranty.**




## Stand Assembly

1. Assemble stand parts together.
2. Place the umbrella post on the stand and secure it to stand parts using the supplied screws and washers.



## Umbrella Assembly

1. Slide the umbrella assembly into the stand post. Ensure the pin in the umbrella shaft sits in the groove in the top of the umbrella post, then tighten it and the two post lock nuts by hand.
2. Push in the spring loaded pins at the top of the umbrella and insert it into the cup at the top of the umbrella assembly. Ensure that the umbrella top "clicks" into position in the cup, otherwise the umbrella will not be stable.



Umbrella shown fully open and in horizontal position.

## Umbrella Adjustment

**To open/close umbrella** - Rotate handle clockwise (right) to open umbrella. Rotate handle anti-clockwise (left) to close umbrella.

**To adjust umbrella angle** - Place clamp in "open" position to unlock it, then slowly slide clamp up or down to change umbrella angle. When set, place clamp in "close" position to lock.



**Some experts believe that the incorrect or prolonged use of almost any product may cause serious injury or death. To help reduce your risk of serious injury or death, refer to the information below. For more information, see [www.datastreamserver.com/safety](http://www.datastreamserver.com/safety)**

- Consult all documentation, packaging and product labelling before use. Note that some products feature documentation available online. It is recommended to print and retain the documentation.
- Before each use, check the product for loose/broken/damaged/missing parts, wear or leaks (if applicable). Never use a product with loose/broken/damaged/missing parts, wear or leaks.
- Products must be inspected and serviced (if applicable) by a qualified technician every 6 months. This is based on average residential use by persons of average size and strength, and on a property of average metropolitan size. Use beyond these recommendations may require more frequent inspections/servicing.
- Ensure that all users of the product have completed a suitable industry recognised training course before being allowed access to the product.
- If this product has been purchased in error when considering the information presented here, contact the retailer directly for details of their returns policy, if required.
- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or description of application. Be sure to attain third-party approval from a qualified specialist for your application before use, regardless of any assurances from the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (for example, automobile, computer, toaster), there is the possibility of technical issues that may require the repair or replacement of parts, or the product itself. If the possibility of such failure and the associated time it may take to rectify could in any way inconvenience the user, business or employee, or financially affect the user, business or employee, then the product is not suitable for your requirements. This product is not intended for use where incorrect operation or a failure of any kind, including but not limited to, a condition requiring product return, replacement, parts replacement or service by a technician may cause financial loss, loss of employee time or an inconvenience requiring compensation.

