



Colours may vary

Kids Ride-On Mini ATV

User Manual

[Revision 2.0 April 2020]

READ THIS MANUAL CAREFULLY BEFORE USE – FAILURE TO DO SO MAY RESULT IN INJURY, PROPERTY DAMAGE AND MAY VOID WARRANTY. • KEEP THIS MANUAL FOR FUTURE REFERENCE. • Products covered by this manual may vary in appearance, assembly, inclusions, specifications, description and packaging.

**THE BATTERY MAY HAVE SOME CHARGE ON ARRIVAL, IT IS IMPORTANT
HOWEVER THAT THE BATTERY IS CHARGED PRIOR TO USE.**

Safety

Safety messages are designed to alert you to possible dangers or hazards that could cause death, injury or equipment or property damage if not understood or followed. Safety messages have the following symbols:



You **WILL** be KILLED or SERIOUSLY INJURED if you do not follow instructions.



You **CAN** be KILLED or SERIOUSLY INJURED if you do not follow instructions.



You **CAN** be INJURED if you do not follow instructions or equipment damage may occur.

It is vital that you read and understand this user manual before using the product, including safety warnings, and any assembly and operating instructions. Keep the manual for future reference.

Safety precautions and recommendations detailed here must be fully understood and followed to reduce the risk of injury, fire, explosion, electrical hazard, and/or property damage.

Safety information presented here is generic in nature – some advice may not be applicable to every product. The term "equipment" refers to the product, be it electrical mains powered, battery powered or combustion engine powered.

- Before Use** - If you are not familiar with the safe operation/handling of the equipment or are in any way unsure of any aspect of suitability or correct use for your application, you should complete training conducted by a person or organization qualified in safe use and operation of this equipment, including fuel/electrical handling and safety.

- Do NOT operate the equipment in flammable or explosive environments, such as in the presence of flammable liquids, gases or dust. The equipment may create sparks or heat that may ignite flammable substances.
- Keep clear of moving parts.
- Equipment may be a potential source of electric shock or injury if misused.
- Do NOT operate the equipment if it is damaged, malfunctioning or is in an excessively worn state.
- Do NOT allow others to use the equipment unless they have read this manual and are adequately trained.
- Keep packaging away from children - risk of suffocation! Operators must use the equipment correctly. When using the equipment, consider conditions and pay due care to persons and property.

General Work Area Safety

- Work areas should be clean and well lit.
- Do not operate the equipment if bystanders, animals etc are within operating range of the equipment or the general work area.
- If devices are provided for connecting dust extraction / collection facilities, ensure these are connected and used properly. Dust collection can reduce dust-related hazards.

General Personal Safety

- Wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect from eye and ear injury, poisoning, burns, cutting and crush injuries. Protective equipment such as safety goggles, respirators, non-slip safety footwear, hard hat, hearing protection etc should be used for appropriate equipment / conditions. Other people nearby should also wear appropriate personal protective equipment. Do not wear loose clothing or jewellery, which can be caught in moving parts. Keep hair and clothing away from the equipment.
- Stay alert and use common sense when operating the equipment. Do not over-reach. Always maintain secure footing and balance.
- Do not use the equipment if tired or under the influence of drugs, alcohol or medication.
- This equipment is not intended for use by persons with reduced physical, sensory or mental capabilities.

General Fuel Safety

- Petrol/fuel/gasoline is extremely flammable – keep clear of naked flames or other ignition sources.
- Do not spill fuel. If you spill fuel, wipe it off the equipment immediately – if fuel gets on your clothing, change clothing.
- Do NOT smoke near fuel or when refuelling.
- Always shut off the engine before refuelling.
- Do NOT refuel a hot engine.
- Open the fuel cap carefully to allow any pressure build-up in the tank to release slowly.
- Always refuel in well ventilated areas.
- Always check for fuel leakage. If fuel leakage is found, do not start or run the engine until all leaks are fixed.

General Carbon-Monoxide Safety

- Using a combustion engine indoors **CAN KILL IN MINUTES**. Engine exhaust contains carbon-monoxide – a poison you cannot smell or see.
- Use combustion engines **OUTSIDE** only, and far away from windows, doors and vents.

General Equipment Use and Care

- The equipment is designed for domestic use only.
- Handle the equipment safely and carefully.
- Before use, inspect the equipment for misalignment or binding of moving parts, loose components, damage or any other condition that may affect its operation. If damaged, have the equipment repaired by an authorised service centre or technician before use.
- Prevent unintentional starting of the equipment - ensure equipment and power switches are in the OFF position before connecting or moving equipment. Do not carry equipment with hands or fingers touching any controls. Remove any tools or other items that are not a part of the equipment from it before starting or switching on.
- Do not force the equipment. Use the correct equipment for your application. Equipment will perform better and be safer when used within its design and usage parameters.
- Use the equipment and accessories etc. in accordance with these instructions, considering working conditions and the work to be performed. Using the equipment for operations different from those intended could result in hazardous situations.
- Always keep equipment components (engines, hoses, handles, controls, frames, housings, guards etc) and accessories (cutting tools, nozzles, bits etc) properly maintained. Keep the equipment clean and, where applicable, properly lubricated.
- Store the equipment out of reach of children or untrained persons. To avoid burns or fire hazards, let the equipment cool completely before transporting or storing. Never place or store the equipment near flammable materials, combustible gases or liquids etc.
- The equipment is not weather-proof, and should not be stored in direct sunlight, at high ambient temperatures or locations that are damp or humid.
- Do not clean equipment with solvents, flammable liquids or harsh abrasives.
- For specific equipment safety use and care, see Equipment Safety.

General Electrical Safety	General Electrical Safety	General Service Information
<ul style="list-style-type: none"> Inspect electrical equipment, extension cords, power bars, and electrical fittings for damage or wear before each use. Repair or replace damaged equipment immediately. Ensure all power sources conform to equipment voltage requirements and are disconnected before connecting or disconnecting equipment. When wiring electrically powered equipment, follow all electrical and safety codes. Wherever possible, use a residual current device (RCD). High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal. 	<ul style="list-style-type: none"> Electrically grounded equipment must have an approved cord and plug and be connected to a grounded electrical outlet. Do NOT bypass the ON/OFF switch and operate equipment by connecting and disconnecting the electrical cord. Do NOT use equipment that has exposed wiring, damaged switches, covers or guards. Do NOT use electrical equipment in wet conditions or in damp locations. Do NOT use electrical cords to lift, move or carry equipment. Do NOT coil or knot electrical cords, and ensure electrical cords are not trip hazards. 	<ul style="list-style-type: none"> The equipment must be serviced or repaired at authorised service centres by qualified personnel only. Replacement parts must be original equipment manufacturer (OEM) to ensure equipment safety is maintained. Do NOT attempt any maintenance or repair work not described in this manual. After use, the equipment and components may still be hot – allow the equipment to cool and disconnect spark plugs and/or electrical power sources and/or batteries from it before adjusting, changing accessories or performing repair or maintenance. Do NOT adjust while the equipment is running. Perform service related activities in suitable conditions, such as a workshop. Replace worn, damaged or missing warning/safety labels immediately.

Kids Ride On Safety

PREVENT INJURIES AND DEATHS:

- NEVER LEAVE CHILD UNATTENDED. ADULT DIRECT SUPERVISION IS REQUIRED.** Always keep child in view when child is in vehicle.
- This toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.
- Protective equipment should be worn.
- Never use in roadways, near cars, on or near steep inclines or steps, swimming pools or other bodies of water.
- Always wear shoes, always sit on the seat.
- Not to be used in traffic.
- This toy is unsuitable for children under 36 months due to its maximum speed; Maximum user weight is 35 kgs.
- This toy has no brake.
- CHOKING HAZARD!** NOT suitable for children under 37 months.
- ADULT ASSEMBLY REQUIRED.**
- Keep children within Safe Riding Areas: Never use in roadway near motor vehicles, on lawn space, on or near steep inclines or steps, swimming pools or other bodies of water.
- Use the toy only on flat surfaces such as inside your house, garden or playground.
- Never use in the dark. A child could encounter unexpected obstacles and have an accident. Operate the vehicle only in the daytime or a well-lit area.
- DO NOT change the circuitry or add other electrical parts.
- Inspect wires and connections of the vehicle periodically.
- Do not let any child touch the wheels or be near them when the car is moving.
- This vehicle has adjustable play seat belts. Please instruct children how to tie the safety belt before using to guarantee their safety.

Battery and Charger Safety

- Do not recharge non-rechargeable batteries.
- If removable rechargeable batteries are to be used, they should only be charged under close adult supervision.
- Remove the rechargeable batteries from the ride-on car first before charging them.
- Do not mix old and new batteries. Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Insert the batteries as indicated inside the battery compartment. Anode to anode and cathode to cathode.
- Remove the batteries when not in use for extended periods. Always remove depleted batteries from the ride-on car. Battery leakage and corrosion can damage this product. Dispose of batteries safely.
- Never short-circuit the battery terminals.
- Use only rechargeable batteries and charger supplied with your vehicle. NEVER substitute the battery or charger with another brand. Using another battery or charger may cause a fire or explosion.
- Do not use the batteries or charger for any other product. Overheating, fire or explosion could occur.
- NEVER modify the electric circuit system! Tampering with the electric system may cause shocks, fires or explosion or permanently damaging the internal system.
- Do not allow direct contact between battery terminals. Fire or explosion can occur.
- Do not allow any type of liquid to make contact with the battery or its components.
- Explosive gases could be created during charging. Do not charge near flammable materials.



Kids Ride-On Mini ATV

- Charge the battery in a well-ventilated area only.
- DO NOT TURN ON THE BATTERY AND CHARGER. DO NOT TURN THE BATTERY BACK UP.
- Check the charger, battery and plug before charging. If any damage is found, stop using the charger until it is repaired or replaced.
- Battery heating during charging is a normal phenomenon, but when the temperature is too high, it should be timely to check whether the charging current is too large or whether the battery has short-circuited.
- The battery must be fixed with a pressure plate. If the car turns over, the battery could hurt children if it falls out.
- Do not allow the battery to drain completely. Recharge the battery after each use or once a month of not being used regularly.
- The charger and battery are not toys. Children are not allowed to play with them.
- The POWER SWITCH must be turned in the OFF position when charging.
- Before the first usage, you should charge the battery for 8-12 hours. Do not recharge the battery for more than 10 hours to avoid overheating the charger.
- When the vehicle begins to run slowly, recharge the battery.
- After each use or once a month, minimum recharge times are 8 to 12 hours, less than 20 hours at most.

Safety Symbols

The product may have safety warning labels attached to it, explained below. Understand the symbols on your product and their meanings. If any stickers become unreadable, unattached etc., replace them.


 <p>Flammable Material Hazard Flammable liquids, gases or substances etc may present. Avoid ignition sources and open flames. Danger of fire.</p>	 <p>Read User Manual Read and fully understand product safety warnings, operation, procedures etc before using the product.</p>	 <p>Use Hand Protection Wear appropriate hand protection and take due care as the product or use of the product may present hand hazards.</p>	 <p>WARNING EXHAUST FUMES Carbon-Monoxide Hazard Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.</p>
 <p>Electrocution / Electrical Shock Hazard High voltage or high current electricity may be present or required by the product. Take due care when handling electrical products, cables, plugs and leads. Electrical shock can be fatal.</p>	 <p>Toxic Fumes / Dust Hazard Using the product or by-products from use may produce fumes, smoke or particles that could be harmful if inhaled. Wear appropriate breathing protection and have adequate ventilation.</p>	 <p>Explosive Material Hazard Combustible liquids, gases or substances etc may be present. Avoid ignition sources and open flames. Danger of explosion.</p>	 <p>Cutting / Amputation Hazard The product may have blades, edges or mechanical devices that can cause severe cut injury to fingers, limbs etc. Take due care when handling and using the product.</p>
 <p>Crush Hazard The product may have blades, edges or mechanical devices that can cause severe crush injury to fingers, limbs etc. Take due care when handling and using the product.</p>	 <p>Single Operator Only The product must be operated by a single person only. More than one person operating the product may introduce additional hazards.</p>	 <p>Use Face Protection Wear appropriate full-face protection and take due care as the product or use of the product may present face and eye hazards.</p>	 <p>Use Foot Protection Wear appropriate foot protection and take due care as the product or use of the product may present foot hazards.</p>
 <p>Use Eye / Ear / Head Protection Wear appropriate eye and / or ear and / or head protection and take due care as the product or use of the product may present eye, hearing and head hazards.</p>	 <p>Running Hazard Do not run on or near the product as doing so may present a fall hazard.</p>	 <p>Diving Hazard Do not dive into the product as doing so may present a neck / head injury hazard.</p>	 <p>Adult Supervision Required Always supervise children and other users of a product to prevent drowning or injury.</p>
 <p>Skin Penetration / Puncture Hazard The product may produce pressure, emit liquids or objects that can cause severe injury to fingers, limbs, blood etc. Take due care when handling and using the product.</p>	 <p>Hot Surface Hazard Be aware that the product may produce high temperatures and hot surfaces that can cause burn injuries.</p>	 <p>Flying Debris Hazard Be aware that the product or use of the product may present hazards produced by flying debris. Wear appropriate clothing and protective devices.</p>	 <p>Moving Parts Hazard Be aware that the product contains or uses mechanical devices that move or rotate. Always wait for moving parts to stop fully before handling the product, adjusting, maintenance etc.</p>

 <p>Carbon-Monoxide Hazard Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.</p>	 <p>Pull Hazard Be aware that the product contains or uses mechanical devices that can pull in objects and can cause severe injury to fingers, limbs etc. Take due care when handling and using the product.</p>	 <p>Slope / Fall Injury Hazard Be aware that using the product on sloping surfaces or in slippery conditions may present additional dangers from falls and contact with blades, moving parts, hot surfaces etc.</p>	 <p>"Slam Dunk" Warning Do NOT attempt "slam dunk" manoeuvres as this may result in severe injury due to falling, product breakage or collapse etc.</p>
 <p>Electrocution / Electrical Shock Hazard - Outdoor High voltage or high current electricity may be present or required by the product. Do NOT use in rain, damp or wet conditions. Electrical shock can be fatal.</p>	 <p>Electrocution / Electrical Shock Hazard - Disconnect High voltage or high current electricity may be present or required by the product. Always disconnect the product from the electrical supply before handling the product, adjusting, maintenance etc.</p>	 <p>Power Line Electrocution Hazard High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal.</p>	 <p>"Kick-Back" Hazard High level of "kick-back" hazard that can cause the machine to suddenly rotate towards operator. Kick-back injury can be fatal.</p>
 <p>Winch Operator Position Hazard Do NOT stand between winch and load. Do NOT use winch to move people.</p>	 <p>Winch Lift Hazard Do NOT LIFT load vertically. Use machine to PULL only.</p>	 <p>Cable Hazard Ensure that load bearing cable is not kinked or knotted.</p>	 <p>Winch Cable Hazard Ensure that there is a minimum number of cable coils on winching mechanism.</p>
 <p>Winch Hook Hazard Carry hook to load – do NOT throw or run.</p>	 <p>Flash / Blinding Hazard Wear appropriate eye protection for welding. Direct exposure to weld arcs may cause permanent eye injury.</p>	 <p>Laser Hazard Laser may be in use – do NOT look directly at laser or allow others to.</p>	

Table of Contents

Safety	2
Safety Symbols	5
Parts Identification	8
Assembly and Set-Up	9
Tools Required	9
Installing the Front and Rear Wheels	10
Installing the Front Bumper	11
Installing the Steering Rod and Wheel	12
Connecting the Battery	13
Operation	14
Control Buttons	14
Charging Instructions	14
Replacing the Batteries	15
Lithium Battery Care and Maintenance	16
Top 3 Battery Care Requirements	16
Maintenance	17
Fuse	17
Battery Replacement and Disposal	17
Troubleshooting	18
Specifications	19


Parts Identification



No.	Name	Quantity <input type="checkbox"/> unit: pcs <input type="checkbox"/>		Remarks
		Single drive	Double drive	
1	Steering wheel	1	1	
2	Wheel	4	4	
3	Wheel trim	4	4	
4	Front bumper	1	1	
5	Sleeve wrench	2	2	
6	Charger	1	1	
A/C	Ø10 gasket	7	6	Double drive: 6PCS, remaining spare
B	M10 nut	4	4	Spare
D	M5 screw	1	1	Install on steering rods
E	M5 nut	1	1	Install on steering rods

Assembly and Set-Up

Tools Required



Video Tutorial:
[Typical Ride-On Car Assembly](#)



NOTE: Please remove the terminal cover first when assembling the battery (see image below).



Installing the Front and Rear Wheels



Turn the car upside-down.

1. Insert a ø12 gasket into the front axle.
2. Install one front wheel.
3. Insert a ø10 gasket.
4. Use a sleeve wrench to secure the M10 nut.
5. Install the wheel hub.

Use the same procedure to install the other front wheel on the other side.




1. Insert the shock absorber sleeve and spring into the corresponding hole in the body.
2. Insert the rear axle into the body and then through the hole of the shock absorber sleeve, which is symmetrical left and right.
3. Install the drive motor on the rear axle and connect the drive motor wire to the receiver connection wire.
4. Install the driving wheel on the rear axle and push it flush onto the drive motor so it is engaging the gear section.
5. Install a ø10 gasket on the rear axle.
6. Secure the driving wheel with a sleeve wrench and a self-locking nut.

7. Clip in the wheel cover.

Use the same procedure to install the other wheel on the other side (the installation of a single drive motor without a motor side is the same as the installation of the front wheel).

Installing the Front Bumper



1. Clip the front bumper into the corresponding body slot and fix it with M4* 10 large flat head screws.
2. Secure the front bracket and front bumper with M4* 10 large flat head screws.

Installing the Steering Rod and Wheel




1. Insert the steering rod into the slot of the steering connector, then insert (A) Ø10 gasket into the steering rod, align the holes between the steering rod and the steering connector, and put the bottom of the steering rod into the slot of the steering bracket.
2. Insert the steering wheel into the end of the steering rod, align the holes on the steering wheel with the holes on the steering rod, insert the Ø5 screw on the other side to screw in the Ø5 nut, and tighten the Ø5 screw with the cross screwdriver (self-provided).


NOTE: You should be able to distinguish between front and rear steering wheels.

Connecting the Battery

1. Take out the 2pcs M4*10 screws on the seat and take it off.



2. Insert the power cord plug into the receiver's corresponding slot.



Operation


Control Buttons



1. **Power button:** turns the vehicle ON or OFF.
2. **Directional button:** changes the direction of the car (forward-stop-backward).
3. **Music button (if equipped):** Press for sounds or to play music.
4. **Horn**
5. **MP3 player (if equipped)**
6. **Power display:** Displays the remaining battery power.
7. **Charger socket**
8. **Pedal:** Stepping on it will move the vehicle. Releasing it will make the star stop slowly.

PLEASE NOTE: Not all units are equipped with music, stories, songs, MP3, AUX or SD card functionality. Please refer to the product listing.

Charging Instructions



1. Insert the charger jack into the charging hole of the car.



Kids Ride-On Mini ATV

2. Insert the charger into a stable matching AC power supply.
3. The location of the charging jack is on the dashboard.

IMPORTANT! Only an adult can charge and recharge the battery.

Replacing the Batteries

1. When replacing a replaceable battery, first open the lid and take out the old battery. Put in the new battery, paying close attention to the positive and negative poles. Then, cover the lid again.
2. Rechargeable batteries should be removed from the vehicle before charging them.
3. Because of a built-in charge protection function, all vehicle functions are unavailable during battery charging.

Lithium Battery Care and Maintenance

Top 3 Battery Care Requirements

1. **Charge battery before first use.** The battery may arrive with some charge, regardless of this the battery must be charged for 8 – 12 hours on the initial charge and 8 hours for each subsequent charge. 
2. **Charge battery immediately when it is depleted.** Do not store a depleted battery. This will permanently impact the life of the battery. If the battery is going to be stored for a period of time, fully charge the battery before storing. 
3. **Disconnect battery when not in use.** To prolong the life of a battery, disconnect it from the unit when not in use. Disconnect chargers from the battery once charged. 

To ensure the battery maintains optimum performance, follow the guidelines outlined below.

- For best results, charge batteries in temperatures between 10°C and 30°C
- When battery is charged, disconnect the charger from the power supply and remove the battery from the charger.
- If a battery is stored or otherwise unused for an extended period, and the battery has no charge remaining when you check it, consider it to be damaged. Do not attempt to recharge it or to use it. Replace it with a new battery.
- Use only with the battery charger specified by the manufacturer.
- Ensure that the battery charger electrical cord is not subjected to damage or stress. Do not operate the battery charger if it has a damaged electrical cord or plug.
- Do not use the charger in wet areas or expose it to rain or water.
- The typical estimated life of a Lithium-Ion battery is about two to three years or 300 to 500 charge cycles, whichever occurs first. One charge cycle is a period of use from fully charged, to fully discharged, and fully recharged again.
- Explosion hazard – protect the battery against heat; for example, direct sunlight and fire. Do not store batteries in vehicles or locations subject to heat.
- Batteries can explode in the presence of an ignition source, such as a pilot light. To reduce the risk of serious personal injury, never use any cordless product in the presence of open flame. Exploding batteries can propel debris and chemicals.
- Do not open the battery – danger of short-circuiting and/or explosion.
- Do not attempt to destroy or disassemble the battery pack or remove any of its components.
- Do not touch the battery terminals with metal objects and/or body parts as short-circuit and/or personal injury may result.
- Explosion hazard – do not open and/or short-circuit the battery.
- Poison hazard – battery leakage (liquid ejection). Under extreme conditions, liquid may be ejected from the battery – avoid contact. If contact accidentally occurs, immediately seek medical attention, and flush with water. If liquid contacts eyes, immediately seek medical attention, flush with clean water for at least 10 minutes. Liquid ejected from the battery may cause irritation or burns.
- Dispose of non-serviceable batteries in an environmentally responsible manner and according to local regulations.

Failure to adhere to the requirements above may result in the battery becoming inoperative or battery life being reduced. In extreme cases or abuse, battery overheating or fire may result.

Maintenance

Fuse

This product is equipped with a self-reset fuse. When overloaded or subjected to improper usage, the self-reset fuse will automatically cut off the power supply for 15-20 seconds, and then restart. The self-reset fuse of the car is installed under the seat.

To avoid losing power, follow these guidelines:

- Do not overload the vehicle, maximum 35kgs.
- Do not tow anything behind the vehicle.
- Do not allow water or other liquid to come in contact with the battery or other electric components.
- Do not tamper with the electric system. Replacement must be conducted by professionals or under the guidance of technicians.

Battery Replacement and Disposal

- Check the charger's wires, plugs, housing and other components before use. Stop using the charger when damage is found. Repair or replace it, as needed.
- After a period of time, lubricate the parts of the vehicle with a small amount of lubricating oil to prevent wear and rust.
- Vehicles should be placed far away from heat/fire sources and avoid long-term sun exposure. Keep it flat and facing upwards, not upside down or tilted. In wet/rainy weather, parked it indoors or cover it with a waterproof cloth.
- Vehicles should be kept away from hot objects such as stoves and heaters. Plastic parts may melt. When charging, keep away from flammable materials to prevent fires from starting.
- After each use, please charge in a timely manner. Charging must be done by an adult. If you don't have to charge the battery for an extended time, charge it at least once a month to extend the battery life.
- Wipe the vehicle with a dry, soft cloth. Non-waxy furniture polishing material can also be used instead of soft cloth to wipe plastic parts to achieve surface finish effect. Do not use chemical solvents to wipe plastic parts of toys. Do not use soap and water to clean vehicles. Do not drive in rainy or snowy weather. Water can damage motors, electrical systems and batteries.
- When you stop using the vehicle, please cut off its power supply and dial all switches to the stop or close positions.
- Please do not use fuses that is not in conformity with the specifications of this product.
- Do not alter the structure and circuit system of the product without proper authorisation. Maintenance work must be carried out under the guidance of professional or technical personnel.

Troubleshooting

Checkpoint	Possible Solutions
<ol style="list-style-type: none"> 1. Is the fuse of the vehicle disconnected? 2. Does the foot switch contact well? 3. Is the welding line on the motor terminal good? 4. Is the connector of the motor lead properly connected? 5. Is it turning the disconnect the plug-in of the motor and directly connect it to the battery? 	<ol style="list-style-type: none"> 1. Yes, cut off the power for 15-20 seconds and then restart. No, next step. 2. No, fix the foot switch. Yes, next step. 3. No, weld the terminal wire well. Yes, next step. 4. No, install plug-ins. Yes, next step. 5. No, change motor. Yes, driving circuit boards need professional maintenance, contact agents or distributors.
<ol style="list-style-type: none"> 1. Check whether the battery voltage is normal. 2. Will the motor (Gearbox) directly connect to the battery and speed up? 	<ol style="list-style-type: none"> 1. No, charge. Yes, next step. 2. Yes, drive circuit board failure, contact agent or dealer.
<ol style="list-style-type: none"> 1. Is the battery plug loose? 2. Does the charger feel slightly hot when charging? 	<ol style="list-style-type: none"> 1. Yes, lock battery plug in. No, next step. 2. No, maybe the charger is broken. Replace the charger.
No sounds and lights while driving.	<ol style="list-style-type: none"> 1. If equipped, is the music button still functional? 2. Check whether the line and plug-ins from battery to vehicle are good. <ol style="list-style-type: none"> 1. No, change button. Yes, next step. 2. No, plug in the plug-in and connect the broken line
Wheels do not move.	<ol style="list-style-type: none"> 1. Is the drive rotating? 2. Check gear box, gear at all levels are damaged. <ol style="list-style-type: none"> 1. Yes, land the wheel. No next step. 2. Yes, replace with a new gearbox.
The vehicle is moving, then suddenly stops.	<ol style="list-style-type: none"> 1. Does the rider weigh more than 35 kilograms? 2. Is it driving in rough terrain? 3. Check that the horizontal wheel can turn itself? <ol style="list-style-type: none"> 1. Yes, normal. 2. Yes, normal. The vehicle should run on a flat, smooth road. No, next step. 3. No, remove wheel and wheel fault
Remote control vehicles do not respond.	<ol style="list-style-type: none"> 1. Is the brake pedal engaged? 2. Is the remote control turned on? 3. Is the receiver wiring harness loose? <ol style="list-style-type: none"> 1. Yes, press the brake key to relieve the brake function. No, normal. 2. Yes, try again. No, check whether the battery is out of power and whether the installation is in place. 3. Yes, remove the row, then reinstall. No, normal.

If the user is not available to perform the above troubleshooting methods, please contact authorised agents or distributors.

Specifications

Speed Range	3-5km/h
Gears	Forward and Reverse
Motor	40W (2 x 20W)
Suspension	Yes
Max Capacity	30kg
Suitable Age	3-7 Years Old
Power Plug	Australian Standard



Some experts believe that the incorrect or prolonged use of almost any product may cause serious injury or death. To help reduce your risk of serious injury or death, refer to the information below. For more information, see www.datastreamserver.com/safety

- Consult all documentation, packaging and product labelling before use. Note that some products feature documentation available online. It is recommended to print and retain the documentation.
- Before each use, check the product for loose/broken/damaged/missing parts, wear or leaks (if applicable). Never use a product with loose/broken/damaged/missing parts, wear or leaks.
- Products must be inspected and serviced (if applicable) by a qualified technician every 6 months. This is based on average residential use by persons of average size and strength, and on a property of average metropolitan size. Use beyond these recommendations may require more frequent inspections/servicing.
- Ensure that all users of the product have completed a suitable industry recognised training course before being allowed access to the product.
- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or description of application. Be sure to attain third-party approval from a qualified specialist for your application before use, regardless of any assurances from the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (for example, automobile, computer, toaster), there is the possibility of technical issues that may require the repair or replacement of parts, or the product itself. If the possibility of such failure and the associated time it may take to rectify could in any way inconvenience the user, business or employee, or financially affect the user, business or employee, then the product is not suitable for your requirements. This product is not intended for use where incorrect operation or a failure of any kind, including but not limited to, a condition requiring product return, replacement, parts replacement or service by a technician may cause financial loss, loss of employee time or an inconvenience requiring compensation.
- If this product has been purchased in error when considering the information presented here, contact the retailer directly for details of their returns policy, if required.

