



Colours may vary

Kids Electric Ride-on Car- Audi R8

User Manual

[Revision 5.0 November 2019]

READ THIS MANUAL CAREFULLY BEFORE USE – FAILURE TO DO SO MAY RESULT IN INJURY, PROPERTY DAMAGE AND MAY VOID WARRANTY. • KEEP THIS MANUAL FOR FUTURE REFERENCE. • Products covered by this manual may vary in appearance, assembly, inclusions, specifications, description and packaging.

**THE BATTERY MAY HAVE SOME CHARGE ON ARRIVAL, IT IS IMPORTANT
HOWEVER THAT THE BATTERY IS CHARGED PRIOR TO USE.**

Safety

Safety messages are designed to alert you to possible dangers or hazards that could cause death, injury or equipment or property damage if not understood or followed. Safety messages have the following symbols:

	You WILL be KILLED or SERIOUSLY INJURED if you do not follow instructions.		You CAN be KILLED or SERIOUSLY INJURED if you do not follow instructions.		You CAN be INJURED if you do not follow instructions or equipment damage may occur.
<p>It is vital that you read and understand this user manual before using the product, including safety warnings, and any assembly and operating instructions. Keep the manual for future reference.</p> <p>Safety precautions and recommendations detailed here must be fully understood and followed to reduce the risk of injury, fire, explosion, electrical hazard, and/or property damage.</p> <p>Safety information presented here is generic in nature – some advice may not be applicable to every product. The term "equipment" refers to the product, be it electrical mains powered, battery powered or combustion engine powered.</p> <ul style="list-style-type: none"> Before Use - If you are not familiar with the safe operation/handling of the equipment, or are in any way unsure of any aspect of suitability or correct use for your application, you should complete training conducted by a person or organization qualified in safe use and operation of this equipment, including fuel/electrical handling and safety. Do NOT operate the equipment in flammable or explosive environments, such as in the presence of flammable liquids, gases or dust. The equipment may create sparks or heat that may ignite flammable substances. Keep clear of moving parts. Equipment may be a potential source of electric shock or injury if misused. Do NOT operate the equipment if it is damaged, malfunctioning or is in an excessively worn state. Do NOT allow others to use the equipment unless they have read this manual and are adequately trained. Keep packaging away from children - risk of suffocation! Operators must use the equipment correctly. When using the equipment, consider conditions and pay due care to persons and property. <p>General Work Area Safety</p> <ul style="list-style-type: none"> Work areas should be clean and well lit. Do not operate the equipment if bystanders, animals etc are within operating range of the equipment or the general work area. If devices are provided for connecting dust extraction / collection facilities, ensure these are connected and used properly. Dust collection can reduce dust-related hazards. 	<p>General Personal Safety</p> <ul style="list-style-type: none"> Wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect from eye and ear injury, poisoning, burns, cutting and crush injuries. Protective equipment such as safety goggles, respirators, non-slip safety footwear, hard hat, hearing protection etc should be used for appropriate equipment / conditions. Other people nearby should also wear appropriate personal protective equipment. Do not wear loose clothing or jewellery, which can be caught in moving parts. Keep hair and clothing away from the equipment. Stay alert and use common sense when operating the equipment. Do not over-reach. Always maintain secure footing and balance. Do not use the equipment if tired or under the influence of drugs, alcohol or medication. This equipment is not intended for use by persons with reduced physical, sensory or mental capabilities. <p>General Fuel Safety</p> <ul style="list-style-type: none"> Petrol/fuel/gasoline is extremely flammable – keep clear of naked flames or other ignition sources. Do not spill fuel. If you spill fuel, wipe it off the equipment immediately – if fuel gets on your clothing, change clothing. Do NOT smoke near fuel or when refuelling. Always shut off the engine before refuelling. Do NOT refuel a hot engine. Open the fuel cap carefully to allow any pressure build-up in the tank to release slowly. Always refuel in well ventilated areas. Always check for fuel leakage. If fuel leakage is found, do not start or run the engine until all leaks are fixed. <p>General Carbon-Monoxide Safety</p> <ul style="list-style-type: none"> Using a combustion engine indoors CAN KILL IN MINUTES. Engine exhaust contains carbon-monoxide – a poison you cannot smell or see. Use combustion engines OUTSIDE only, and far away from windows, doors and vents. 	<p>General Equipment Use and Care</p> <ul style="list-style-type: none"> The equipment is designed for domestic use only. Handle the equipment safely and carefully. Before use, inspect the equipment for misalignment or binding of moving parts, loose components, damage or any other condition that may affect its operation. If damaged, have the equipment repaired by an authorised service centre or technician before use. Prevent unintentional starting of the equipment - ensure equipment and power switches are in the OFF position before connecting or moving equipment. Do not carry equipment with hands or fingers touching any controls. Remove any tools or other items that are not a part of the equipment from it before starting or switching on. Do not force the equipment. Use the correct equipment for your application. Equipment will perform better and be safer when used within its design and usage parameters. Use the equipment and accessories etc. in accordance with these instructions, considering working conditions and the work to be performed. Using the equipment for operations different from those intended could result in hazardous situations. Always keep equipment components (engines, hoses, handles, controls, frames, housings, guards etc) and accessories (cutting tools, nozzles, bits etc) properly maintained. Keep the equipment clean and, where applicable, properly lubricated. Store the equipment out of reach of children or untrained persons. To avoid burns or fire hazards, let the equipment cool completely before transporting or storing. Never place or store the equipment near flammable materials, combustible gases or liquids etc. The equipment is not weather-proof, and should not be stored in direct sunlight, at high ambient temperatures or locations that are damp or humid. Do not clean equipment with solvents, flammable liquids or harsh abrasives. For specific equipment safety use and care, see Equipment Safety. 			

General Electrical Safety	General Electrical Safety	General Service Information
<ul style="list-style-type: none"> Inspect electrical equipment, extension cords, power bars, and electrical fittings for damage or wear before each use. Repair or replace damaged equipment immediately. Ensure all power sources conform to equipment voltage requirements and are disconnected before connecting or disconnecting equipment. When wiring electrically powered equipment, follow all electrical and safety codes. Wherever possible, use a residual current device (RCD). High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal. 	<ul style="list-style-type: none"> Electrically grounded equipment must have an approved cord and plug and be connected to a grounded electrical outlet. Do NOT bypass the ON/OFF switch and operate equipment by connecting and disconnecting the electrical cord. Do NOT use equipment that has exposed wiring, damaged switches, covers or guards. Do NOT use electrical equipment in wet conditions or in damp locations. Do NOT use electrical cords to lift, move or carry equipment. Do NOT coil or knot electrical cords, and ensure electrical cords are not trip hazards. 	<ul style="list-style-type: none"> The equipment must be serviced or repaired at authorised service centres by qualified personnel only. Replacement parts must be original equipment manufacturer (OEM) to ensure equipment safety is maintained. Do NOT attempt any maintenance or repair work not described in this manual. After use, the equipment and components may still be hot – allow the equipment to cool and disconnect spark plugs and/or electrical power sources and/or batteries from it before making adjustments, changing accessories or performing repair or maintenance. Do NOT make adjustments while the equipment is running. Perform service related activities in suitable conditions, such as a workshop. Replace worn, damaged or missing warning/safety labels immediately.
Special Instructions		Rules for Safe Riding
<ul style="list-style-type: none"> NEVER LEAVE CHILD UNATTENDED. DIRECT ADULT SUPERVISION IS REQUIRED. Always keep child in view when child is in vehicle. This toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties. Protective equipment should be worn. Never use in roadways, near cars, on or near steep inclines or steps, swimming pools or other bodies of water. Always wear shoes. Always sit on the seat. Not to be used in traffic. This toy is unsuitable for children under 18 months due to its maximum speed; Maximum user weight is 30 kgs. This toy has no brake. 		<ul style="list-style-type: none"> Keep Children within safe riding areas; never use in roadway, near motor vehicles, on lawn space, on or near steep inclines or steps, swimming pools or other bodies of water; Use the toy only on flat surfaces. Such as inside your house, garden or playground. Never use in the dark. A child could encounter unexpected obstacles and have an accident. Operate the motorbike only in the daytime or a well-lit area. DO NOT change the circuit or add other electric parts. Inspect wires and connections of the motorbike periodically. Do not let any child touch the wheels or be near them when the car is moving.



Safety Symbols

The product may have safety warning labels attached to it, explained below. Understand the symbols on your product and their meanings. If any stickers become unreadable, unattached etc, replace them.

 <p>Flammable Material Hazard Flammable liquids, gases or substances etc may present. Avoid ignition sources and open flames. Danger of fire.</p>	 <p>Read User Manual Read and fully understand product safety warnings, operation, procedures etc before using the product.</p>	 <p>Use Hand Protection Wear appropriate hand protection and take due care as the product or use of the product may present hand hazards.</p>	 <p>Carbon-Monoxide Hazard Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.</p>
 <p>Electrocution / Electrical Shock Hazard High voltage or high current electricity may be present or required by the product. Take due care when handling electrical products, cables, plugs and leads. Electrical shock can be fatal.</p>	 <p>Toxic Fumes / Dust Hazard Using the product or by-products from use may produce fumes, smoke or particles that could be harmful if inhaled. Wear appropriate breathing protection and have adequate ventilation.</p>	 <p>Explosive Material Hazard Combustible liquids, gases or substances etc may be present. Avoid ignition sources and open flames. Danger of explosion.</p>	 <p>Cutting / Amputation Hazard The product may have blades, edges or mechanical devices that can cause severe cut injury to fingers, limbs etc. Take due care when handling and using the product.</p>
 <p>Crush Hazard The product may have blades, edges or mechanical devices that can cause severe crush injury to fingers, limbs etc. Take due care when handling and using the product.</p>	 <p>Single Operator Only The product must be operated by a single person only. More than one person operating the product may introduce additional hazards.</p>	 <p>Use Face Protection Wear appropriate full-face protection and take due care as the product or use of the product may present face and eye hazards.</p>	 <p>Use Foot Protection Wear appropriate foot protection and take due care as the product or use of the product may present foot hazards.</p>
 <p>Use Eye / Ear / Head Protection Wear appropriate eye and / or ear and / or head protection and take due care as the product or use of the product may present eye, hearing and head hazards.</p>	 <p>Running Hazard Do not run on or near the product as doing so may present a fall hazard.</p>	 <p>Diving Hazard Do not dive into the product as doing so may present a neck / head injury hazard.</p>	 <p>Adult Supervision Required Always supervise children and other users of a product to prevent drowning or injury.</p>
 <p>Skin Penetration / Puncture Hazard The product may produce pressure, emit liquids or objects that can cause severe injury to fingers, limbs, blood etc. Take due care when handling and using the product.</p>	 <p>Hot Surface Hazard Be aware that the product may produce high temperatures and hot surfaces that can cause burn injuries.</p>	 <p>Flying Debris Hazard Be aware that the product or use of the product may present hazards produced by flying debris. Wear appropriate clothing and protective devices.</p>	 <p>Moving Parts Hazard Be aware that the product contains or uses mechanical devices that move or rotate. Always wait for moving parts to stop fully before handling the product, adjusting, maintenance etc.</p>

 <p>Carbon-Monoxide Hazard Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.</p>	 <p>Pull Hazard Be aware that the product contains or uses mechanical devices that can pull in objects and can cause severe injury to fingers, limbs etc. Take due care when handling and using the product.</p>	 <p>Slope / Fall Injury Hazard Be aware that using the product on sloping surfaces or in slippery conditions may present additional dangers from falls and contact with blades, moving parts, hot surfaces etc.</p>	 <p>"Slam Dunk" Warning Do NOT attempt "slam dunk" manoeuvres as this may result in severe injury due to falling, product breakage or collapse etc.</p>
 <p>Electrocution / Electrical Shock Hazard - Outdoor High voltage or high current electricity may be present or required by the product. Do NOT use in rain, damp or wet conditions. Electrical shock can be fatal.</p>	 <p>Electrocution / Electrical Shock Hazard - Disconnect High voltage or high current electricity may be present or required by the product. Always disconnect the product from the electrical supply before handling the product, adjusting, maintenance etc.</p>	 <p>Power Line Electrocution Hazard High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal.</p>	 <p>"Kick-Back" Hazard High level of "kick-back" hazard that can cause the machine to suddenly rotate towards operator. Kick-back injury can be fatal.</p>
 <p>Winch Operator Position Hazard Do NOT stand between winch and load. Do NOT use winch to move people.</p>	 <p>Winch Lift Hazard Do NOT LIFT load vertically. Use machine to PULL only.</p>	 <p>Cable Hazard Ensure that load bearing cable is not kinked or knotted.</p>	 <p>Winch Cable Hazard Ensure that there is a minimum number of cable coils on winching mechanism.</p>
 <p>Winch Hook Hazard Carry hook to load – do NOT throw or run.</p>	 <p>Flash / Blinding Hazard Wear appropriate eye protection for welding. Direct exposure to weld arcs may cause permanent eye injury.</p>	 <p>Laser Hazard Laser may be in use – do NOT look directly at laser, or allow others to.</p>	



Table of Contents

Safety	2
Safety Symbols	4
Parts Identification	7
Assembly	8
Installing the Rear Drive Wheels.....	8
Installing the Front Wheels.....	9
Installing the Steering Wheel	9
Installing the Mirror.....	10
Connecting the Battery.....	10
Installing the Seat.....	10
Installing the Windscreen and Side Mirrors	10
Syncing the Remote Control	11
Remote Control Functions	11
Functionality Instructions.....	11
In-Car Controls	11
Lithium Battery Care and Maintenance	13
Top 3 Battery Care Requirements	13
Charging the Battery	14
Troubleshooting	15
Specifications	16

Parts Identification

Name	Qty.
Car body	1
Steering wheel	1
Seat	1
Car wheels	4
Charger	1
MP3 connector	1
Remote control	1
Windscreen	1
Hub Caps	4
Axle Caps	4

Assembly



Video Tutorial:

[Typical Ride-On Car Assembly](#)



Installing the Rear Drive Wheels

1. Turn the car over to easily access the axles.
2. Fit a hub cap (**A**) to each of the wheels (**B**)
3. Remove the tape securing the drive motors in place; and slide the drive motors off the rear axle (**C**). Place one of the large washers onto each side of the axle. Reinstall the drive motors.
4. Place the rear drive wheels (**D**), with drive gear facing inward, onto the axle. Ensure that the drive teeth engage the drive motor assemblies correctly, then place one of the small washers (**E**) on the axle, then screw (rotate right) a wheel nut (**F**) onto the axle until "finger-tight". Use the supplied wheel nut spanners and simultaneously tighten both rear wheel nuts. Ensure that the wheels are secure, however, the nuts are not so tight as to prevent the wheels from spinning freely.



Installing the Front Wheels


1. Place a large washer (**G**) on to each front axle (**H**).
2. Install the hubcaps to all 4 of the wheels. Place a front wheel (**I**) onto the axle, then place a small washer (**J**) on the axle, then screw (rotate right) a wheel nut (**K**) onto the axle and tighten using the supplied wheel nut spanner. Ensure that the wheels are secure, however, the nuts are not so tight as to prevent the wheels from spinning freely.



NOTE: The hubcaps must be installed to all 4 wheels before securing them to the axle.

Installing the Steering Wheel

1. Remove the bolt (**L**) from the steering wheel stem. Plug the toy and steering wheel electrical connectors (**M** and **N**) together. Feed excess wire into the steering column housing (**O**).
2. Ensure the front wheels are straight then slide the steering wheel stem (**P**) onto the steering shaft (**Q**) – ensure that the steering wheel stem screw hole aligns with the hole in the shaft. If the steering shaft appears to be too short, pull it up as there is free space on the opposite end of the shaft.
3. Insert the bolt (**R**) from the other side of the steering wheel stem, passing through the steering shaft and into the nut. Adequately tighten the screw with an appropriate screwdriver.





Installing the Mirror

First, identify which are the left and right mirrors, respectively, and then install them in their correct positions on the car.

Next, insert the left and right doors.

Connecting the Battery

1. Remove the clear cover from the battery terminal (**S**)
2. Locate the loose, black battery wire (**T**) and firmly push onto the free battery terminal (**S2**).



Installing the Seat

1. Ensure the seat belt straps are pulled out to the side so they do not get stuck under the seat.
2. Slide the two tabs at the back of the seat into the slots in the body of the car, fasten the seat in place with 2 screws at point (**U**).



Installing the Windscreen and Side Mirrors

1. Align the tabs at the bottom of the windscreens with the slots in the main body of the car. Carefully push the windscreens down so it is properly located by the tabs/slots and "clips" into place.
2. Identify the left and right mirrors and carefully push them into the slots on the side of the car until they clip into place.



Syncing the Remote Control

1. Ensure the car is turned off, with the key in the ignition.
2. Insert two AAA 1.5 V batteries into the back of the remote control.
3. The remote control will flash, turn the key in the ignition to on, the car and remote will automatically sync.

Remote Control Functions




NOTE: When the brake button is pressed, the brake will stay on. To release the brake, press the brake button again.

Functionality Instructions

In-Car Controls

- **Power Switch:** Turns the power ON/OFF.
- **Forward and Reverse Gear:** Operate it together with the **Gas Pedal** to make the vehicle go forward/backward and left/right with the Steering Wheel.



Kids Electric Ride-on Car- Audi R8



Lithium Battery Care and Maintenance

Top 3 Battery Care Requirements

1. **Charge battery before first use.** The battery may arrive with some charge, regardless of this the battery must be charged for 8 – 12 hours on the initial charge and 1 – 2 hours for each subsequent charge. 
2. **Charge battery immediately when it is depleted.** Do not store a depleted battery. This will permanently impact the life of the battery. If the battery is going to be stored for a period of time, fully charge the battery before storing. 
3. **Disconnect battery when not in use.** To prolong the life of a battery, disconnect it from the unit when not in use. Disconnect chargers from the battery once charged. 

To ensure the battery maintains optimum performance, follow the guidelines outlined below.

- For best results, charge batteries in temperatures between 10°C and 30°C
- When battery is charged, disconnect the charger from the power supply and remove the battery from the charger.
- If a battery is stored or otherwise unused for an extended period, and the battery has no charge remaining when you check it, consider it to be damaged. Do not attempt to recharge it or to use it. Replace it with a new battery.
- Use only with the battery charger specified by the manufacturer.
- Ensure that the battery charger electrical cord is not subjected to damage or stress. Do not operate the battery charger if it has a damaged electrical cord or plug.
- Do not use the charger in wet areas or expose it to rain or water.
- The typical estimated life of a Lithium-Ion battery is about two to three years or 300 to 500 charge cycles, whichever occurs first. One charge cycle is a period of use from fully charged, to fully discharged, and fully recharged again
- Explosion hazard – protect the battery against heat; for example, direct sunlight and fire. Do not store batteries in vehicles or locations subject to heat.
 - Batteries can explode in the presence of an ignition source, such as a pilot light. To reduce the risk of serious personal injury, never use any cordless product in the presence of open flame. Exploding batteries can propel debris and chemicals.
 - Do not open the battery – danger of short-circuiting and/or explosion.
 - Do not attempt to destroy or disassemble the battery pack or remove any of its components.
 - Do not touch the battery terminals with metal objects and/or body parts as short-circuit and/or personal injury may result.
 - Explosion hazard – do not open and/or short-circuit the battery.
 - Poison hazard – battery leakage (liquid ejection). Under extreme conditions, liquid may be ejected from the battery – avoid contact. If contact accidentally occurs, immediately seek medical attention, and flush with water. If liquid contacts eyes, immediately seek medical attention, flush with clean water for at least 10 minutes. Liquid ejected from the battery may cause irritation or burns.
 - Dispose of non-serviceable batteries in an environmentally responsible manner and according to local regulations.

Failure to adhere to the requirements above may result in the battery becoming inoperative or battery life being reduced. In extreme cases or abuse, battery overheating or fire may result.



Charging the Battery

- First to use please open the cushion, and the battery connections with main distributing frame, with red in red and black in black, not a line ends meet, or cause a short-circuit.
- Charging socket, the cushion down side, and needs recharging. charger plug in the outlet, then insert the power outlet.
- The train slowly, in charge, the time for 8-10 hours, and not more than ten hours.
- In the first to use the deposit, we must ensure that the cell battery up to 10 hours. otherwise, permanent damage cells and beyond repair.
- Charging devices or battery which has a fever (60 C) are normal.
- The electric baby must use this car is equipped with the charger and the battery, in the case of broken the cell phone chargers and the counter-voltage or an electric circuit.
- Have to recharge the batteries to be recharged from the toy the use of battery.
- Not mixed with the old and new or different types of batteries.
- Can't insert the battery wire connector.
- When the baby is not use for a long time, at least once every month to charge.
- Toys can't connect to the surplus on the use of the recommended amount.
- When the car is charging, can't use it.

Troubleshooting

Problem	Possible Cause	Solution
Car doesn't work	Low power	Recharge the battery
	Damage of thermic fuse	Change with new thermic fuse
	Loss of wheel nut	Use new nut
	Loose of battery connector	Put on the connector
	Exhaust & bad battery	Change with new battery
	Damage on electrical parts	Go to repair shop
	Damage on motor	Go to repair shop
Battery can't be recharged	Loose of the battery connector	Tighten the connector
	Charger doesn't plug the power	Plug charger with power
	Damage of charger	Change new charger
Short of run time	Battery with lower power	Recharge the battery fully
	Battery is old	Change new battery
Noise & Heat during recharge	It's chemical process	It's normal & safety
Low Speed	Old battery	Use new battery
	Low power	Recharge the battery fully
	Over burden	Reduce burden under 25KG
	Run on not-flat ground	Run on flat ground
Noise of gear box	Damage of gear box	Go to repair shop
	Damage on motor	Go to repair shop
Car shake when running	Bad connect of motor wire	Reconnect the wire
	Motor doesn't work well	Go to repair shop
No sound & light when running	Loose of sound & light wire	Connect the wire
	Damage of sound & light board	Go to repair shop
Car can't stop in run	Damage of electrical parts	Go to repair shop
Unusual working condition under Remote control	Remote control battery exhaust	Change battery
	Remote control out of distance	Keep near distance between car and remote control
	Damage of remote control	Damage of remote control
	Damage of receiver board	Change receiver board
	Disturb of magnetic field	Far away from magnetic field

Specifications

Officially Licensed	Audi
Model	R8 Spyder
Motor	50W (2 x 25W)
Speed Range	3-5km/h
Speeds	High Speed / Low Speed
Gears	Forward and Reverse
Max Load	30kg
Keystart Engine	Yes
Seatbelt	Adjustable
Battery	12V (2 x 6V)
Battery Charger	240V 50/60Hz
Charge Time	6-8hrs (full charge)
Drive Time	1-2hrs (full charge)
Remote Operation	Yes
Max User Height	110cm



Some experts believe that the incorrect or prolonged use of almost any product may cause serious injury or death. To help reduce your risk of serious injury or death, refer to the information below. For more information, see www.datastreamserver.com/safety

- Consult all documentation, packaging and product labelling before use. Note that some products feature documentation available online. It is recommended to print and retain the documentation.
- Before each use, check the product for loose/broken/damaged/missing parts, wear or leaks (if applicable). Never use a product with loose/broken/damaged/missing parts, wear or leaks.
- Products must be inspected and serviced (if applicable) by a qualified technician every 6 months. This is based on average residential use by persons of average size and strength, and on a property of average metropolitan size. Use beyond these recommendations may require more frequent inspections/servicing.
- Ensure that all users of the product have completed a suitable industry recognised training course before being allowed access to the product.
- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or description of application. Be sure to attain third-party approval from a qualified specialist for your application before use, regardless of any assurances from the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (for example, automobile, computer, toaster), there is the possibility of technical issues that may require the repair or replacement of parts, or the product itself. If the possibility of such failure and the associated time it may take to rectify could in any way inconvenience the user, business or employee, or financially affect the user, business or employee, then the product is not suitable for your requirements. This product is not intended for use where incorrect operation or a failure of any kind, including but not limited to, a condition requiring product return, replacement, parts replacement or service by a technician may cause financial loss, loss of employee time or an inconvenience requiring compensation.
- If this product has been purchased in error when considering the information presented here, contact the retailer directly for details of their returns policy, if required.



©2019 Rovo Kids. All rights reserved. No part of this document, including descriptive content, concepts, ideas, diagrams or images may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, scanning or recording, or any information storage and retrieval system, without express permission or consent from the publisher.